



Programming Guide

Advanced 2D Image Scanner

This Programming Guide is intended for:

- **2D Image Scan Module: Z-5652 Ultra**

Revision History

Changes to the original manual are listed below:

Version	Date	Description of Version
1.0	2019-06-03	Initial release
1.1	2019/07/23	Added Data Redundant Checks for UPC-A, EAN-8, Code 39, Code 93, Interleaved 2 of 5, PDF417
1.2	2019/08/29	Added GS1 DataBar Expanded Stacked, GS1 DataBar 14 Stacked
1.3	2020/02/07	Default parameter added
1.4	2020/4/23	Truncate/Return example added
1.5	2020/9/15	Continue scan mode description revised
1.6	2022/3/17	JAN code for Books Separator revised

Important Notice

No warranty of any kind is made in regard to this material, including, but not limited to, implied warranties of merchantability or fitness for any particular purpose. We are not liable for any errors contained herein nor for incidental or consequential damages in connection with furnishing, performance or use of this material. We shall be under no liability in respect of any defect arising from fair wear and tear, willful damage, negligence, abnormal working conditions, failure to follow the instructions and warnings, or misuse or alteration or repair of the products without written approval. No part of this document may be reproduced, transmitted, stored in a retrieval system, transcribed, or translated into any human or computer or other language in any form or by any means electronic, mechanical, magnetic, optical, chemical, biological, manual or otherwise, except for brief passages which may be quoted for purposes of scholastic or literary review, without express written consent and authorization. We reserve the right to make changes in product design without reservation and without notification. The material in this guide is for information only and is subject to change without notice. All trademarks mentioned herein, registered or otherwise, are the properties of their various, ill, assorted owners.

General Handling Precautions

- Do not dispose the scanner in fire.
- Do not put the scanner directly in the sun or by any heat source.
- Do not use or store the scanner in a very humid place.
- Do not drop the scanner or allow it to collide violently with other objects.
- Do not take the scanner apart without authorization

Guidance for Printing

This manual is in A5 size. Please double check your printer setting before printing it out. When the barcodes are to be printed out for programming, the use of a high-resolution laser printer is strongly suggested for the best scan result.

Firmware Notice

To use all functions in this guide please update to the latest firmware.

Copyright © 2020 ZEBEX INDUSTRIES INC. All rights reserved.

Table of Contents

Important Notice.....	ii
General Handling Precautions.....	ii
Guidance for Printing	ii
Default Parameters	1
Factory Default Setting.....	1
Using the Scanner	3
Beeper Indication.....	3
Settings and Programming.....	4
Program Set Up Flow.....	4
User Preferences	5
Show Version.....	5
System Settings	5
Customer's Factory Default.....	6
Scan Mode	7
Standby Time for Auto Scan, High Resolution, and Motion Modes.....	9
Same Code Delay Time for Auto Scan, High Resolution, and Phone Modes.....	11
Motion Detect Sensibility for Auto scan, Motion, and Hi resolution Modes	12
Gain Level for Auto scan, continue, and Hi resolution Modes	13
Interface Switch.....	14
Good Read Beep On/ Off.....	15
Good Read Beep Length.....	16
Good Read Beep Frequency	17
Aiming Pattern	18
Illumination	19
Terminal Character.....	20
RS232 Baud Rate	21
RS232 Parity Bit.....	23
RS232 Stop Bit	24
RS232 Data Bit.....	25
USB Speed	26
Country Code	27
Persian/Arabic Language Encoding Support.....	33
Readable Symbologies	34
All Symbologies	34
UPC-A	35
UPC-E.....	36
EAN-8	37
EAN 13.....	38
JAN code for Books.....	39
Code 128	40

Code 39	41
Code 93	42
Code 32	43
Code 11	44
Codabar	45
Plessey	46
MSI/Plessy	47
Interleaved 2 of 5	48
IATA 2 of 5	49
Matrix 2 of 5	50
Straight 2 of 5	51
RSS 14 (GS1 DATABAR 14)	52
RSS Expanded (GS1 DATABAR Expanded)	53
RSS Limited (GS1 DATABAR Limited)	54
Component CC-A	55
Component CC-B	56
Component CC-C	57
PDF417	58
Micro PDF417	59
Data Matrix	60
QR Code	61
Micro QR Code	62
GS1-2D AIM ID	63
GS1-128 AIM ID	64
GS1 DataBar Expanded Stacked	65
GS1 DataBar 14 Stacked	66
Aztec	67
Pharmacode	68
MaxiCode	69
Symbology Features	70
UPC / EAN	70
UPC-A	71
UPC-A Data Redundant Check	73
UPC-E	74
EAN 8	76
EAN 8 Data Redundant Check	77
EAN 13	78
EAN 13 Data Redundant Check	80
JAN code for Books Separator	81
Code 39	83
Code 39 Data Redundant Check	85
Codabar	86

Codabar Redundant Check.....	88
Code 93 Data Redundant Check.....	89
Code 128 Redundant Check	90
Interleaved 2 of 5	91
Interleaved 2 of 5 Data Redundant Check.....	93
MSI / Plessey	94
Code 11	96
Data Matrix	97
QR / Micro QR	98
Japanese Language Encoding Support	100
Aztec.....	101
FNC1 GS Substitution Values.....	102
Code 32 (Italian Pharmacode).....	103
PDF-417 Data Redundant Check	104
Matrix 2 of 5.....	105
Straight 2 of 5.....	106
Data Editing (Prefix)	107
Prefix Set Up Flow	107
All Prefix	108
UPC / EAN Prefix.....	109
Code 128 Prefix	111
Code 39 Prefix	112
Code 93 Prefix	113
Code 32 Prefix	114
Code 11 Prefix	115
Codabar Prefix.....	116
Plessey Prefix.....	117
MSI Prefix	118
Interleaved 2 of 5Prefix	119
IATA 2 of 5 Prefix	120
Matrix 2 of 5 Prefix.....	121
Straight 2 of 5 Prefix.....	122
RSS 14 Prefix (GS1 DATABAR 14 Prefix)	123
RSS Expanded Prefix (GS1 DATABAR Expanded Prefix).....	124
RSS Limited Prefix (GS1 DATABAR Limited Prefix)	125
Component CC-A Prefix.....	126
Component CC-B Prefix.....	127
Component CC-C Prefix.....	128
PDF 417 Prefix	129
Micro PDF 417 Prefix.....	130
Data Matrix Prefix	131
QR Prefix	132

Micro QR Prefix	133
Aztec Prefix.....	134
MaxiCode Prefix	135
Data Editing (Suffix).....	136
Suffix Set Up Flow.....	136
All Suffix	137
UPC-A Suffix	138
UPC-E Suffix.....	139
EAN 8 Suffix.....	140
EAN 13 Suffix.....	141
Code 128 Suffix	142
Code 39 Suffix	143
Code 93 Suffix	144
Code 32 Suffix	145
Code 11 Suffix	146
Codabar Suffix	147
Plessey Suffix.....	148
MSI Suffix	149
Interleaved 2 of 5 Suffix	150
IATA 2 of 5 Suffix.....	151
Matrix 2 of 5 Suffix	152
Straight 2 of 5 Suffix	153
RSS 14 Suffix (GS1 DATABAR 14 Suffix).....	154
RSS Expanded Suffix (GS1 DATABAR Expanded Suffix)	155
RSS Limited Suffix (GS1 DATABAR Limited Suffix)	156
Component CC-A Suffix.....	157
Component CC-B Suffix	158
Component CC-C Suffix	159
PDF-417 Suffix	160
Micro PDF-417 Suffix.....	161
Data Matrix Suffix.....	162
QR Code Suffix.....	163
Micro QR Suffix	164
Aztec Suffix.....	165
MaxiCode Suffix	166
Data Editing (Truncate/Return)	167
Truncate/Return Set Up Flow	167
Set All Symbologies Truncate/Return.....	168
Set UPC-A Truncate/Return.....	170
Set UPC-E Truncate/Return	172
Set EAN-8 Truncate/Return	174
Set EAN 13 Truncate/Return	176

Set Code 128 Truncate/Return.....	178
Set Code 39 Truncate/Return.....	180
Set Code 93 Truncate/Return.....	182
Set Code 32 Truncate/Return.....	184
Set Code 11 Truncate/Return.....	186
Set Codabar Truncate/Return	188
Set Plessey Truncate/Return	190
Set MSI (Modified Plessy) Truncate/Return	192
Set Interleaved 2 of 5 Truncate/Return	194
Interleaved 2 of 5 (ITF).ReturnLeft.4	196
Set IATA 2 of 5 Truncate/Return	197
Set Matrix 2 of 5 Truncate/Return	199
Set Straight 2 of 5 Truncate/Return	201
Set RSS 14 (GS1 DataBar) Truncate/Return	203
Set RSS Expanded (GS1 DataBar Expanded) Truncate/Return	205
Set RSS Limited (GS1 DataBar Limited) Truncate/Return	207
Set Component CC-A Truncate/Return	209
Set Component CC-B Truncate/Return.....	211
Set Component CC-C Truncate/Return.....	213
Set PDF 417 Truncate/Return	215
Set Micro PDF 417 Truncate/Return	217
Set Data Martrix Truncate/Return.....	219
Set QR Truncate/Return	221
Set Micro QR Truncate/Return	223
Set Aztec Truncate/Return	225
Set MaxiCode Truncate/Return.....	227
Code Settings	229
Set Lengths for Codes.....	229
Set Lengths for Code 128	231
Set Lengths for Code 39	232
Set Lengths for Code 93	233
Set Lengths for Codabar	234
Set Lengths for Interleaved 2 of 5	235
Set Lengths for Code 11	236
Set Lengths for MSI	237
Set Lengths for Matrix 2 of 5	238
Code Identifiers	239
Code Identifiers Table	240
Keyboard Caps Lock State	241
Function Key Mapping	243
Function Key Extended.....	244
ASCII Code	245

USB Virtual COM Driver Installing	265
JavaPOS Setting	266
JavaPOS	266
JavaPOS Version	267
Install the Java2 Runtime Environment.....	267
Install the Service Object and JavaPOS files.....	267
How to use RS232 scanner with JavaPOS Driver	267
Use barcodes to configure the scanner.....	268
Running the JavaPOS Test utility	269
How to use JavaPOS driver at your application.....	269
How to use USB scanner with JavaPOS Driver	270
Install the Java RXTXcomm API	271
Running the JavaPOS Test utility	271
How to Use JavaPOS Driver at your application	272

Default Parameters

The factory default setting table gives the default settings of all the programmable parameters. The default settings will be restored whenever the "Reset" programming label is scanned and the scanner is in programming mode. Default values are highlighted in grey background in the settings.

Factory Default Setting

Scanner Operation

User Preferences	
Parameter	Default
Baud Rate	9600 BPS
Interface	USB Keyboard
Good read beep length	50 msec
Terminal character	CR/LF
Country code	US

Symbologies

Symbology	Default
UPC-A	Enable
UPC-E	Disable
EAN-8	Enable
EAN 13	Enable
JAN code for Books	Disable
Code 128	Enable
Code 39	Enable
Code 93	Enable
Code 32	Disable
Code 11	Disable
Codabar	Enable
Plessey	Disable
MSI/Plessy	Disable
Interleaved 2 of 5	Enable
IATA 2 of 5	Disable
Matrix 2 of 5	Disable
Straight 2 of 5	Disable
RSS 14	Enable
RSS Expanded	Enable
RSS Limited	Enable
Component CC-A	Disable
Component CC-B	Disable
Component CC-C	Disable
PDF417	Enable
Micro PDF417	Enable
Data Matrix	Enable
QR Code	Enable
Micro QR Code	Enable
GS1-2D AIM ID	Disable
GS1-128 AIM ID	Disable
GS1 DataBar Expanded Stacked	Disable
GS1 DataBar 14 Stacked	Disable
Aztec	Disable
MaxiCode	Disable

Using the Scanner

Beeper Indication

Beeps	Indication
3 beeps in a series from low to high pitch	Power up
1 short beep	A barcode has been successfully decoded
2 short beeps	The scanner has entered program mode
1 long beep	A setting has been programmed
3 beeps in a series from low to high pitch	The scanner has exited program mode
3 short beeps	Error setting the scanner

Settings and Programming

Scan selected barcodes in this manual to affect setup and programming of your 2D image barcode scanner. Decoding options and interface protocols can be tailored to a specific application.

Setup parameters are stored in non-volatile memory in the scanner and are retained even when power is off. Setup parameters change only when you reset them. You may need to hide adjacent code patches with your hand when scanning.

Program Set Up Flow

Scan "Set" to set up --> Scan selected barcode --> Scan "End" to confirm the setup.

User Preferences

Show Version


Scan this barcode to display firmware version.




Read device information

System Settings


Scan this barcode to return all parameters to the default values.



Set




Factory default settings



End

Customer's Factory Default

Scan barcodes below to set or delete customer's factory default.




Set



Save customer's factory default



Delete customer's factory default



End

Scan Mode

Scan a barcodes below to set the scanner to different modes.


Trigger Mode: The scanner becomes inactive as soon as the data is transmitted by pressing the trigger button.

Auto Scan Mode: The scanner is still active after the data is transmitted but the successive transmission of the same code is not allowed.

Continue Scan Mode: scans periodically non-stop.



Set




Trigger Mode




Auto Scan Mode (Default)



Continue Scan Mode



End



Set



Motion Mode



End




High Resolution Mode



Phone Mode

Standby Time for Auto Scan, High Resolution, and Motion Modes

Use the barcodes below to set the standby time for the applicable modes.



Set



1 minute




3 minutes




5 minutes (Default)



10 minutes



End



Set



15 minutes




20 minutes



25 minutes




30 minutes



End

Same Code Delay Time for Auto Scan, High Resolution, and Phone Modes

Scan a barcode below to select the duration of the delay time for the applicable modes.



Set



500 msec (Default)




1 sec



1.5 sec




2 sec



End

Motion Detect Sensibility for Auto scan, Motion, and Hi resolution Modes

Scan a barcode below to select the motion detect sensibility for the applicable modes.



Set



Level 1 (Low)



Level 2




Level 3 (Default)



Level 4



Level 5 (High)



End

Gain Level for Auto scan, continue, and Hi resolution Modes

Scan a barcode below to select the gain level for the applicable modes.



Set



Level 1 (Low)



Level 2




Level 3 (Default)



Level 4



Level 5 (High)




End

Interface Switch


Your 2D Imager supports interfaces such as USB HID, RS232 serial, and USB virtual COM. To switch the interface, simply select the appropriate cable and configure the proper interface by following interface selection.




Set



RS-232




USB Keyboard



USB Virtual COM Port


*Driver required



End

Good Read Beep On/ Off

Scan a barcode below to turn on/off good read beep.




Set



Off



On (Default)



End

Good Read Beep Length

Scan a barcode below to select the duration of the beep signal after a good decode.



Set



50 msec (Default)




100 msec



150 msec



200 msec



End

Good Read Beep Frequency

Scan a barcode below to select the beep tone of the beep signal after a good decode.



Set



Low



Medium (Default)




High



End

Aiming Pattern

Aiming pattern works as an aiming system to aid in barcode reading. Use the following settings to enable or disable this function. This function is for supporting models only.



Set



Auto (Default)



Always On



Always Off



End

Illumination

Set Illumination to aid in barcode reading. Use the following settings to configure this function.




Set



Auto (Default)



Always On




Always Off




End


Terminal Character




Set




None



CR/LF (Default)



CR



TAB




End

RS232 Baud Rate


Baud rate is the number of bits of data transmitted per second. Set the imager's baud rate to match the baud rate setting of the host device. Otherwise, data may not reach the host device or may reach it in distorted form.




Set




9600 (Default)




19200




38400




57600




End



Set




115200




End

RS232 Parity Bit


Parity bit can be added to ensure the total number of the string is even or odd.




Set



None (Default)



Even parity




Odd parity




End

RS232 Stop Bit


Stop bit is used to signal the end of a transmission.




Set



1 Stop Bit (Default)



2 Stop Bit



End

RS232 Data Bit

Data bit sets the word length at 7 or 8 bits of data per character.




Set



CS7




CS8 (Default)



End

USB Speed

Scan a barcode below to set USB speed.



Set



USB 2.0




USB 1.1 (Default)



End

Country Code


Scann the following settings to change the country code.



Set




US (Default)




Belgium




Britain




Denmark




End




Set



France




Germany




Italy



Norway




End



Set



Portugal



Spain




Sweden




Switzerland




End




Set




Japan



Hungary




Czech Republic



Slovakia




End



Set




Romania




Croatia



Poland



End



Set



International Keyboard mode
(ALT mode)



Turkey-Q




Turkey-F



End

Persian/Arabic Language Encoding Support

Scann the following settings to change the encoding options.



Set



UTF-8 (Default)



ISO 8859-6



CP1256 (WINDOWS-1256)




End

Readable Symbologies

This section provides the programming barcodes for enabling and disabling readable symbologies. If the default values suit requirements, programming is not necessary.

All Symbologies




Set



Enable All



Default



End

UPC-A


Set



Enable UPC-A (Default)




Disable UPC-A



End

UPC-E




Set



Enable UPC-E



Disable UPC-E (Default)



End

EAN-8


Set



Enable EAN 8 (Default)



Disable EAN 8



End

EAN 13




Set



Enable EAN 13 (Default)




Disable EAN 13



End

JAN code for Books


Set



Disable (Default)



Enable



End

Code 128




Set



Disable Code 128



Enable Code 128 (Default)



End

Code 39


Set



Enable Code 39 (Default)



Disable Code 39



End

Code 93



Set




Enable Code 93 (Default)



Disable Code 93



End

Code 32

Set



Enable Code 32




Disable Code 32 (Default)



End

Code 11




Set




Enable Code 11



Disable Code 11 (Default)



End

Codabar


Set



Enable Codabar (Default)




Disable Codabar



End

Plessey



Set




Enable Plessey



Disable Plessey (Default)



End

MSI/Plessy

Set



Enable MSI/Plessy



Disable MSI/Plessy (Default)



End

Interleaved 2 of 5




Set



Enable Interleaved 2 of 5 (Default)



Disable Interleaved 2 of 5



End

IATA 2 of 5

Set



Enable IATA 2 of 5




Disable IATA 2 of 5 (Default)



End

Matrix 2 of 5



Set



Enable Matrix 2 of 5



Disable Matrix 2 of 5 (Default)



End

Straight 2 of 5

Set



Enable Straight 2 of 5



Disable Straight 2 of 5 (Default)



End

RSS 14 (GS1 DATABAR 14)




Set



Enable RSS 14 (GS1 DATABAR Expanded)
(Default)



Disable RSS 14 (GS1 DATABAR Expanded)



End

RSS Expanded (GS1 DATABAR Expanded)

Set



Enable RSS Expanded (GS1 DATABAR Expanded) (Default)




Disable RSS Expanded (GS1 DATABAR Expanded)



End

RSS Limited (GS1 DATABAR Limited)




Set



Enable RSS Limited (GS1 DATABAR Limited) (Default)



Disable RSS Limited (GS1 DATABAR Limited)



End

Component CC-A


Set



Enable Component CC-A



Disable Component CC-A (Default)



End

Component CC-B




Set




Enable Component CC-B



Disable Component CC-B (Default)



End

Component CC-C


Set



Enable Component CC-C




Disable Component CC-C (Default)



End

PDF417




Set



Enable PDF417 (Default)



Disable PDF417



End

Micro PDF417


Set



Enable Micro PDF417 (Default)



Disable Micro PDF417



End

Data Matrix




Set



Enable Data Matrix (Default)




Disable Data Matrix




End

QR Code




Set



Enable QR Code (Default)




Disable QR Code




End

Micro QR Code




Set



Enable Micro QR Code (Default)




Disable Micro QR Code



End

GS1-2D AIM ID

GS1 2D barcodes (GS1 DataMatrix, GS1 QR Code) output AIM ID Setting.




Set



Enable




Disable (Default)



End

GS1-128 AIM ID

GS1-128 output AIM ID Setting.




Set



Enable



Disable (Default)



End

GS1 DataBar Expanded Stacked

Set



Enable




Disable (Default)



End

GS1 DataBar 14 Stacked




Set




Enable



Disable (Default)



End

Aztec


Set



Enable Aztec



Disable Aztec (Default)



End

Pharmacode

(Pharmaceutical Binary Code)




Set




Enable Pharmacode



Disable Pharmacode (Default)



End

MaxiCode


Set



Enable MaxiCode



Disable MaxiCode (Default)



End

Symbology Features

This section provides the programming barcodes for selecting features available to different symbologies.

UPC / EAN




Set




Enable decoding of 2/5-digit supplemental code for UPC-A, UPC-E, EAN-13, and EAN-8




Disable decoding of 2/5-digit supplemental code for UPC-A, UPC-E, EAN-13, and EAN-8 (Default)




End

UPC-A


Set




Enable UPC-A Number System digit
(Default)




Disable UPC-A Number System digit



Enable UPC-A check digit (Default)




Disable UPC-A check digit




End




Set




Enable conversion of UPC-A to EAN13



Disable conversion of UPC-A to EAN13
(Default)



End

UPC-A Data Redundant Check

Set



Off (Default)




1



2



3




End


UPC-E




Set




Enable UPC-E Number System digit
(Default)




Disable UPC-E Number System digit




Enable UPC-E check digit (Default)




Disable UPC-E check digit





End



Set



Enable conversion of UPC-E to UPC-A


Disable conversion of UPC-E to UPC-A
(Default)

End


EAN 8




Set




Enable EAN 8 check digit (Default)




Disable EAN 8 check digit




Enable conversion of EAN 8 to EAN 13



Disable conversion of EAN 8 to EAN 13
(Default)



End

EAN 8 Data Redundant Check

Set



Off (Default)




1



2



3




End


EAN 13




Set




Enable EAN 13 check digit (Default)



Disable EAN 13 check digit



Enable conversion of EAN 13 to ISBN




Disable conversion of EAN 13 to ISBN
(Default)





End



Set



Enable conversion of EAN 13 to ISSN


Disable conversion of EAN 13 to ISSN
(Default)

End

EAN 13 Data Redundant Check




Set



Off (Default)



1




2



3




End

JAN code for Books Separator

Set



[SPACE] key x 3




End



[TAB] key x 2



[-] dash char




Set




Others char Separator


For parameters requiring specific numeric values, scan the [PROGRAMMING GUIDE\ASCII Code] appropriately numbered barcode(s)




None(Default)




End

Code 39


Set




Disable Code 39 full ASCII mode (Default)



Enable Code 39 full ASCII mode



Disable Start and Stop characters (Default)




Enable Start and Stop characters



End




Set



Disable Checksum (Default)



Enable checksum and send check
character



Enable checksum and strip check
character



End

Code 39 Data Redundant Check

Set



Off (Default)




1



2




3




End

Codabar



Set



Disable Checksum (Default)




Enable checksum and send check character




Enable checksum and strip check character




End



Set

Enable stripping Start and Stop characters
(Default)

Disable stripping Start and Stop characters




End

Codabar Redundant Check



Set



Off



1




2 (Default)



3



End

Code 93 Data Redundant Check

Set



Off (Default)



1



2



3



End

Code 128 Redundant Check



Set



Off



1



2 (Default)




3




End

Interleaved 2 of 5


Set



Disable Checksum (Default)



Enable checksum and send check character




Enable checksum and strip check character




End




Set



Default quiet zone checking
No length checking performed (Default)



Smaller quiet zone allowed



End

Interleaved 2 of 5 Data Redundant Check

Set



Off (Default)




1



2



3




End


MSI / Plessey




Set




Mod 10 checksum (Default)




Mod 11/10 checksum




Set




Disable MSI Plessey checksum



Mod 10/10 checksum




End



Output checksum character(s) (Default)



Strip checksum character(s)




End


Code 11



Set



Output checksum character(s)




Strip checksum character(s) (Default)



Disable checksum checking



Enable 1-digit checksum checking




Enable 2-digit checksum checking
(Default)




End


Data Matrix




Set





Disable mirror decoding



Enable mirror decoding (Default)



Enable rectangular Data Matrix decoding


Disable rectangular Data Matrix decoding
(Default)

End


QR / Micro QR




Set



Disable mirror decoding



Enable mirror decoding (Default)



End




Set



UTF8 conversion for word only



Universal UTF8 conversion (Default)



End

Note: Please install QR_UTF8_Conversion executable file before using this function.

Japanese Language Encoding Support




Set




Enable




Disable (Default)




End

Aztec


Set



Enable mirror decoding (Default)



Disable mirror decoding



End

FNC1 GS Substitution Values




Set



“Ctrl+]” (Default)



“Alt+29(KP)”
(nmvs)



End

Code 32 (Italian Pharmacode)

Set




Transmit

Alphabet "A" char




Disable Transmit
Alphabet "A" char
(Default)



End

PDF-417 Data Redundant Check



Set



Off (Default)




1




2



3




End

Matrix 2 of 5

Set




Disable Checksum (Default)

Enable checksum and send check
characterEnable checksum and strip check
character

End

Straight 2 of 5



Set



Disable Checksum (Default)



Enable checksum and send check
character



Enable checksum and strip check
character



End

Data Editing (Prefix)


Prefix is additional characters that can be sent before the scanned data. Please scan the barcodes in the selection below to set your prefix.

Prefix Set Up Flow


1. Scan Set.
2. Enable barcode type.
3. Scan prefix you would like to add characters within ASCII Code Table. Up to 4 digits can be added.
4. Scan End.

Ex. If we wish to add “3” as prefix for all barcode type, then follow procedure as below, Scan [Set] to enter setup. Then we select barcode by scanning [Enable All], then we scan [3] as 3 of ASCII HEX. At the end, we scan [End] to completed setup.


All Prefix




Set



Enable All




Disable All (Default)




End

UPC / EAN Prefix


Set




Disable UPC-A




Enable UPC-A



Disable UPC-E




Enable UPC-E




End




Set



Enable EAN 8




Disable EAN 8



Enable EAN 13




Disable EAN 13




End

Code 128 Prefix


Set



Disable Code 128



Enable Code 128




End


Code 39 Prefix



Set



Disable Code 39




Enable Code 39




End

Code 93 Prefix


Set



Disable Code 93



Enable Code 93




End


Code 32 Prefix




Set



Disable Code 32




Enable Code 32




End

Code 11 Prefix


Set



Enable Code 11



Disable Code 11




End


Codabar Prefix




Set



Enable Codabar




Disable Codabar




End


Plessey Prefix




Set



Disable Plessey



Enable Plessey




End


MSI Prefix



Set




Enable MSI




Disable MSI




End

Interleaved 2 of 5 Prefix

Set



Enable Interleaved 2 of 5




Disable Interleaved 2 of 5




End


IATA 2 of 5 Prefix




Set




Disable IATA 2 of 5




Enable IATA 2 of 5




End

Matrix 2 of 5 Prefix


Set



Disable Matrix 2 of 5



Enable Matrix 2 of 5




End


Straight 2 of 5 Prefix




Set




Enable Straight 2 of 5




Disable Straight 2 of 5




End

RSS 14 Prefix (GS1 DATABAR 14 Prefix)


Set



Enable RSS 14 (GS1 DATABAR 14 Prefix)




Disable RSS 14 (GS1 DATABAR 14 Prefix)




End


RSS Expanded Prefix (GS1 DATABAR Expanded Prefix)




Set



Enable RSS Expanded (GS1 DATABAR
Expanded Prefix)




Disable RSS Expanded (GS1 DATABAR
Expanded Prefix)




End

RSS Limited Prefix (GS1 DATABAR Limited Prefix)


Set



Enable RSS Limited (GS1 DATABAR Limited Prefix)



Disable RSS Limited (GS1 DATABAR Limited Prefix)




End


Component CC-A Prefix




Set



Enable Component CC-A




Disable Component CC-A




End

Component CC-B Prefix


Set



Enable Component CC-B



Disable Component CC-B




End


Component CC-C Prefix




Set



Enable Component CC-C



Disable Component CC-C




End

PDF 417 Prefix


Set



Disable PDF 417



Enable PDF 417




End


Micro PDF 417 Prefix




Set



Enable Micro PDF 417




Disable Micro PDF 417




End

Data Matrix Prefix


Set



Disable Data Matrix



Enable Data Matrix




End


QR Prefix



Set



Enable QR Code



Disable QR Code




End


Micro QR Prefix




Set



Disable Micro QR



Enable Micro QR




End


Aztec Prefix



Set



Disable Aztec




Enable Aztec




End

MaxiCode Prefix


Set



Disable MaxiCode



Enable MaxiCode



End

Data Editing (Suffix)

Suffix is additional characters that can be sent after the scanned data. Please scan the barcodes in the selection below to set your suffix.


Suffix Set Up Flow

1. Scan Set.
2. Enable barcode type.
3. Scan suffix you would like to add characters within ASCII Code Table. Up to 4 digits can be added.
4. Scan End.


Ex. If we wish to add “36” as suffix for all barcode type, then follow procedure as below. Scan [Set] to enter setup. Then we select barcode by scanning [Enable All], then we scan [3] as 3 of ASCII HEX and [6] as 6.

All Suffix


Set



Disable All (Default)




Enable All




End


UPC-A Suffix




Set



Enable UPC-A



Disable UPC-A




End

UPC-E Suffix

Set



Disable UPC-E




Enable UPC-E




End


EAN 8 Suffix




Set




Disable EAN 8




Enable EAN 8




End

EAN 13 Suffix


Set



Disable EAN 13



Enable EAN 13




End


Code 128 Suffix




Set



Disable Code 128



Enable Code 128




End


Code 39 Suffix




Set



Enable Code 39




Disable Code 39




End


Code 93 Suffix



Set



Disable Code 93




Enable Code 93




End

Code 32 Suffix


Set



Disable Code 32



Enable Code 32




End


Code 11 Suffix




Set



Disable Code 11




Enable Code 11




End


Codabar Suffix




Set



Disable Codabar



Enable Codabar




End


Plessey Suffix



Set



Enable Plessey



Disable Plessey




End

MSI Suffix


Set



Disable MSI



Enable MSI




End


Interleaved 2 of 5 Suffix




Set



Enable Interleaved 2 of 5




Disable Interleaved 2 of 5




End

IATA 2 of 5 Suffix


Set



Disable IATA 2 of 5




Enable IATA 2 of 5




End


Matrix 2 of 5 Suffix




Set



Enable Matrix 2 of 5




Disable Matrix 2 of 5




End

Straight 2 of 5 Suffix


Set



Disable Straight 2 of 5



Enable Straight 2 of 5




End


RSS 14 Suffix (GS1 DATABAR 14 Suffix)




Set



Enable RSS 14 (GS1 DATABAR 14 Suffix)





Disable RSS 14 (GS1 DATABAR 14 Suffix)



End


RSS Expanded Suffix (GS1 DATABAR Expanded Suffix)

Set


Enable RSS Expanded (GS1 DATABAR
Expanded Suffix)Disable RSS Expanded (GS1 DATABAR
Expanded Suffix)

End


RSS Limited Suffix (GS1 DATABAR Limited Suffix)




Set




Enable RSS Limited (GS1 DATABAR Limited Suffix)




Disable RSS Limited (GS1 DATABAR Limited Suffix)




End

Component CC-A Suffix


Set



Enable Component CC-A




Disable Component CC-A




End


Component CC-B Suffix




Set



Enable Component CC-B




Disable Component CC-B




End

Component CC-C Suffix


Set



Enable Component CC-C



Disable Component CC-C




End


PDF-417 Suffix




Set



Enable PDF417




Disable PDF417




End

Micro PDF-417 Suffix


Set



Disable Micro PDF417



Enable Micro PDF417




End


Data Matrix Suffix



Set



Data Matrix Enable



Data Matrix Disable




End


QR Code Suffix




Set



QR Code Enable




QR Code Disable




End


Micro QR Suffix




Set




Micro QR Enable




Micro QR Disable




End

Aztec Suffix


Set



Aztec Disable



Aztec Enable




End


MaxiCode Suffix




Set



MaxiCode Disable



MaxiCode Enable



End

Data Editing (Truncate/Return)

Truncate/Return Commands:

- Return the leftmost characters: Specify the number of leftmost characters you want returned.
- Truncate the leftmost characters: Specify the number of leftmost characters you want deleted.
- Return the Rightmost characters: Specify the number of rightmost characters you want returned.
- Truncate the Rightmost characters: Specify the number of rightmost characters you want deleted.
- Return the Middle characters: Returns the middle characters. The middle is found by scanning from left to right, and parameters determine where the middle begins and ends
- Truncate the Middle characters: Delete the middle characters. The middle is found by scanning from left to right, and parameters determine where the middle begins and ends

Truncate/Return Set Up Flow

1. Scan Set.
2. Enable barcode type.
3. Scan one of Truncate/Return Command.
4. Select lengths using the numeric bar codes in ASCII Code table.
5. Scan End.


For example:

To return the “78” from “078441068255,” scan “Set”, “Return middle” (Return middle of the symbology), “0”, “2”, “0”, “2”, “End”.

To truncate the “78” from “078441068255,” scan “Set”, “Truncate middle” (Truncate middle of the symbology), “0”, “2”, “0”, “2”, “End”.

To disable Truncate/Return, scan “Set”, “Disable” (Disable of the symbology), and “End”.

Set All Symbologies Truncate/Return



Set



Return leftmost




Truncate leftmost




Return rightmost



Truncate rightmost



End



Set



Return middle



Truncate middle



Disable All (Default)



End

Set UPC-A Truncate/Return



Set



Return leftmost




Truncate leftmost




Return rightmost



Truncate rightmost



End



Set




Return middle



Truncate middle



Disable (Default)



End

Set UPC-E Truncate/Return



Set



Return leftmost




Truncate leftmost




Return rightmost



Truncate rightmost



End



Set




Return middle



Truncate middle




Disable (Default)



End

Set EAN-8 Truncate/Return



Set



Return leftmost




Truncate leftmost



Return rightmost



Truncate rightmost



End



Set



Return middle



Truncate middle



Disable (Default)



End

Set EAN 13 Truncate/Return



Set



Return leftmost




Truncate leftmost




Return rightmost



Truncate rightmost



End



Set



Return middle



Truncate middle




Disable (Default)



End

Set Code 128 Truncate/Return



Set



Return leftmost




Truncate leftmost



Return rightmost



Truncate rightmost



End



Set




Return middle



Truncate middle




Disable (Default)



End

Set Code 39 Truncate/Return



Set



Return leftmost




Truncate leftmost




Return rightmost



Truncate rightmost



End



Set



Return middle



Truncate middle




Disable (Default)



End

Set Code 93 Truncate/Return



Set



Return leftmost




Truncate leftmost




Return rightmost



Truncate rightmost



End



Set




Return middle



Truncate middle




Disable (Default)



End

Set Code 32 Truncate/Return



Set



Return leftmost




Truncate leftmost




Return rightmost



Truncate rightmost



End



Set



Return middle



Truncate middle




Disable (Default)



End


Set Code 11 Truncate/Return



Set



Return leftmost



Truncate leftmost




Return rightmost



Truncate rightmost



End



Set




Return middle



Truncate middle



Disable (Default)



End

Set Codabar Truncate/Return



Set



Return leftmost




Truncate leftmost




Return rightmost



Truncate rightmost



End



Set




Return middle



Truncate middle




Disable (Default)



End

Set Plessey Truncate/Return



Set



Return leftmost




Truncate leftmost




Return rightmost



Truncate rightmost



End



Set




Return middle



Truncate middle




Disable (Default)



End

Set MSI (Modified Plessy) Truncate/Return



Set



Return leftmost




Truncate leftmost



Return rightmost



Truncate rightmost



End



Set




Return middle



Truncate middle




Disable (Default)



End

Set Interleaved 2 of 5 Truncate/Return



Set



Return leftmost




Truncate leftmost




Return rightmost



Truncate rightmost



End



Set




Return middle



Truncate middle



Disable (Default)



End


Interleaved 2 of 5 (ITF).ReturnLeft.4



Disable (default)



Enable

Set IATA 2 of 5 Truncate/Return

Set



Return leftmost




Truncate leftmost




Return rightmost



Truncate rightmost



End



Set




Return middle




Truncate middle



Disable (Default)



End

Set Matrix 2 of 5 Truncate/Return

Set



Return leftmost




Truncate leftmost



Return rightmost



Truncate rightmost



End



Set




Return middle




Truncate middle



Disable (Default)



End

Set Straight 2 of 5 Truncate/Return

Set



Return leftmost




Truncate leftmost




Return rightmost



Truncate rightmost



End



Set




Return middle




Truncate middle



Disable (Default)



End

Set RSS 14 (GS1 DataBar) Truncate/Return

Set



Return leftmost




Truncate leftmost




Return rightmost



Truncate rightmost



End



Set




Return middle




Truncate middle



Disable (Default)



End

Set RSS Expanded (GS1 DataBar Expanded) Truncate/Return

Set



Return leftmost



Truncate leftmost




Return rightmost



Truncate rightmost



End



Set




Return middle




Truncate middle



Disable (Default)



End

Set RSS Limited (GS1 DataBar Limited) Truncate/Return

Set



Truncate leftmost




Return leftmost




Truncate rightmost



Return rightmost




End



Set




Return middle




Truncate middle



Disable (Default)



End

Set Component CC-A Truncate/Return

Set



Return leftmost




Truncate leftmost




Return rightmost



Truncate rightmost



End



Set




Return middle



Truncate middle



Disable (Default)



End

Set Component CC-B Truncate/Return

Set



Truncate leftmost




Truncate rightmost




Return leftmost



Return rightmost




End



Set




Return middle




Truncate middle



Disable (Default)



End

Set Component CC-C Truncate/Return

Set



Return leftmost



Truncate leftmost




Return rightmost



Truncate rightmost



End



Set




Return middle



Truncate middle



Disable (Default)



End

Set PDF 417 Truncate/Return

Set




Truncate leftmost




Return leftmost




Truncate rightmost



Return rightmost



End



Set




Return middle




Truncate middle



Disable (Default)



End

Set Micro PDF 417 Truncate/Return

Set



Return leftmost



Truncate leftmost




Return rightmost



Truncate rightmost



End



Set




Return middle




Truncate middle



Disable (Default)



End

Set Data Matrix Truncate/Return

Set



Truncate leftmost




Truncate rightmost




Return leftmost




Return rightmost



End



Set




Return middle




Truncate middle



Disable (Default)



End

Set QR Truncate/Return

Set



Truncate leftmost




Truncate rightmost




Return leftmost



Return rightmost



End



Set




Return middle




Truncate middle



Disable (Default)



End

Set Micro QR Truncate/Return

Set



Truncate leftmost




Truncate rightmost




Return leftmost



Return rightmost



End



Set




Return middle




Truncate middle



Disable (Default)



End

Set Aztec Truncate/Return

Set



Return leftmost




Truncate leftmost




Return rightmost



Truncate rightmost



End



Set




Return middle



Truncate middle



Disable (Default)



End

Set MaxiCode Truncate/Return

Set



Truncate leftmost




Return leftmost




Truncate rightmost



Return rightmost



End



Set




Return middle



Truncate middle



Disable (Default)



End

Code Settings

Set Lengths for Codes

- One Discrete Length

Select this option to decode the symbol containing a selected length.
Select the length using the numeric bar codes in ASCII Code Table.

Example 1:

To decode Interleaved 2 of 5 symbols with 8 characters:

- a. scan Set to set up
- b. scan Interleaved 2 of 5 One Discrete Length
- c. scan 8 in ASCII Code Table
- d. scan End to confirm the setup

Example 2:

To decode Interleaved 2 of 5 symbols with 12 characters:

- a. scan Set to set up
- b. scan Interleaved 2 of 5 One Discrete Length
- c. scan 1 followed by 2 in ASCII Code Table
- d. scan End to confirm the setup

- Two Discrete Lengths

Select this option to decode the symbol containing either of two selected lengths.
Select lengths using the numeric bar codes in ASCII Code Table.

Example:

To decode Code 128 symbols containing either 8 or 14 characters

- a. scan Set to set up
- b. scan Code 128 Two Discrete Length
- c. scan 0, 8, 1, and then 4 in ASCII Code Table
- d. scan End to confirm the setup

- Length Within Range

Select this option to decode the symbol with a specific length range.
Select lengths using numeric bar codes in ASCII Code Table.

Example:

To decode Codabar symbols containing between 7 and 8 characters,


- a. scan Set to set up
- b. scan Codabar Length Within Range
- c. scan 0, 7, 0, and then 8 in ASCII Code Table
- d. scan End to confirm the setup

- Any Length

Select this option to decode the symbol containing any number of characters within the digital scanner's capability.

Example:

- a. scan Set to set up
- b. scan Matrix 2 of 5 Any Length
- c. scan End to confirm the setup

Set Lengths for Code 128

Set



One Discrete Length





Two Discrete Lengths



Length Within Range

Any Length (Default)



End

Set Lengths for Code 39




Set



One Discrete Length




Two Discrete Lengths




Length Within Range



Any Length (Default)



End

Set Lengths for Code 93

Set



Two Discrete Lengths




One Discrete Length



Any Length (Default)




Length Within Range



End

Set Lengths for Codabar




Set



Two Discrete Lengths




Any Length (Default)




One Discrete Length



Length Within Range



End

Set Lengths for Interleaved 2 of 5

Set




One Discrete Length




Two Discrete Lengths



Length Within Range



Any Length (Default)



End

Set Lengths for Code 11



Set



Two Discrete Lengths




One Discrete Length



Any Length (Default)



Length Within Range



End

Set Lengths for MSI



Set



Two Discrete Lengths




Any Length (Default)



One Discrete Length



Length Within Range



End


Set Lengths for Matrix 2 of 5



Set



One Discrete Length




Two Discrete Lengths



Length Within Range




Any Length (Default)



End

Code Identifiers

Scan the following barcodes to set symbology Identifiers.




Set



Disable Code ID (Default)



Enable factory standard ID



Enable AIM ID



End

Code Identifiers Table

Symbology	Factory Standard	AIM
UPC-A	A]E
UPC-E	E]E
EAN 8	FF]E
EAN 13	F]E
Code 128	K]C
Code 39	M]A
Code 93	L]G
Code 32	M]X
Code 11	O]H
Codabar	N]F
Plessey	P]P
MSI / Plessey	a]M
Interleaved 2 of 5	I]I
IATA 2 of 5	Z]R
Matrix 2 of 5	G]X
Straight 2 of 5	S]S
Pharmacode	H]X
RSS 14 (GS1 DATABAR 14)	RS]e
RSS Expanded (GS1 DataBar Expanded)	RX]e
RSS Limited (GS1 DataBar Limited)	RL]e
Component CC-A	m]e
Component CC-B	n]e
Component CC-C	i]e
PDF417	r]L
Micro PDF417	s]L
Data Matrix	t]d
QR	u]Q
Micro QR	j]Q
Aztec	e]Z
MaxiCode	v]U

Keyboard Caps Lock State

Scan a barcode below to turn Caps on or off.




Set



Caps Lock Off (Default)



Caps Lock On



End



Set




Alphabet always Lower case



Alphabet always upper case




Override



End

Function Key Mapping

Scan the following barcodes to enable or disable Function Key Mapping.




Set



Disable Function Key Mapping (Default)




Enable Function Key Mapping




End

Function Key Extended

Scan the following barcodes to enable or disable Function Key Extended. Enable Function Key Extended change the Function Key from [Left-CTRL] to [Right-CTRL].




Set



Disable Function Key Extended (Default)




Enable Function Key Extended



End

ASCII Code


For parameters requiring specific numeric values, scan the appropriately numbered barcode(s).




Space




!




"




#




\$




%




&



!




(









)




*




+







<




=



>




?




@




Enter




0




1




2




3




4




5




6




7



8




9




A

(Function Key
Mapping: Ctrl+a)




B

(Function Key
Mapping: Ctrl+b)




C

(Function Key
Mapping: Ctrl+c)




D

(Function Key
Mapping: Ctrl+d)




E

(Function Key
Mapping: Ctrl+e)




F

(Function Key
Mapping: Ctrl+f)




G


(Function Key
Mapping: Ctrl+g)




H
(Function Key
Mapping: Ctrl+h)




I
(Function Key
Mapping: Ctrl+i)




J
(Function Key
Mapping: Ctrl+j)




K
(Function Key
Mapping: Ctrl+k)




L
(Function Key
Mapping: Ctrl+l)




M
(Function Key
Mapping: Ctrl+m)




N
(Function Key
Mapping: Ctrl+n)




O
(Function Key
Mapping: Ctrl+o)



P
(Function Key
Mapping: Ctrl+p)




Q
(Function Key
Mapping: Ctrl+q)




R

(Function Key
Mapping: Ctrl+r)




S

(Function Key
Mapping: Ctrl+s)




T

(Function Key
Mapping: Ctrl+t)




U

(Function Key
Mapping: Ctrl+u)




V

(Function Key
Mapping: Ctrl+v)




W

(Function Key
Mapping: Ctrl+w)




X

(Function Key
Mapping: Ctrl+x)




Y

(Function Key
Mapping: Ctrl+y)




Z


(Function Key
Mapping: Ctrl+z)




a



b




c




d




e




f




g




h




i




j




k




l




m




n




o




p




q




r




S




T




U




V




W



X



Y




Z



Insert



Delete



Home



End



Up arrow



Down arrow



Left arrow



Right arrow




Tab



Backspace



Shift




ESC



Page up



Page down



F1



F2



F3



F4



F5



F6




F7



F8



F9



F10



F11




F12

USB Virtual COM Driver Installing

If you use virtual COM port emulation, follow the steps below to start using the scanner.

1. Execute the driver (ZEBEX VCOM Driver Installation.exe).
2. Connect the scanner USB cable to the host computer.
3. Set the interface to USB Virtual COM Port.



Set



USB Virtual COM Port
*Driver required



End

4. On the computer, check Device Manager to see if the computer successfully detects the scanner as “Barcode Scanner USB-COM device.” (The COM port number would vary depending on different hardware environment).




JavaPOS Setting

This section provides the programming barcodes for setting JavaPOS and the flow of installing JavaPOS driver.

JavaPOS

Scan the following barcodes to enable or disable JavaPOS.




Set



JPOS Enable



JPOS Disable (Default)



End

JavaPOS Version

Our JavaPOS driver now is compatible with JavaPOS1.7.

Install the Java2 Runtime Environment

The JRE is Java's virtual machine that allows for applications to run on the host computer. To be able to run the JavaPOS application, you need a 1.7 version JRE. Ignore the following steps if you already have a JavaPOS1.7 or a later version in your host computer.

- Go to <http://java.sun.com>, and select this version of Java Runtime Environment.
- Install the program following the instructions.

Install the Service Object and JavaPOS files

In the “\Driver” folder, there are two files: ZbtJavapos.jar and jpos.xml. Please include ZbtJavapos.jar at your CLASSPATH and also copy the related “JPosEntry” option from the jpos.xml to your application’s jpos.xml.

How to use RS232 scanner with JavaPOS Driver

Install the Java RXTXcomm API


In the \RXTXcomm folder, there are four files: rtxSerial.dll , rtxParallel.dll, and RXTXcomm.jar. Please do the following steps to install the library.

1. Copy rtxSerial.dll and rtxParallel.dll to C:\Windows\system32.
2. Copy RXTXcomm.jar to your <JRE Install Folder>\lib directory.


Use barcodes to configure the scanner

JavaPOS configuration barcodes:


Set




RS-232



JPOS Enable



End



Running the JavaPOS Test utility

Please run the test application POStest.sh to evaluate your installation.

How to use JavaPOS driver at your application

1. Add “ZbtJavaPos.jar” from the “\Driver” folder to the CLASSPATH and copy the related “JPosEntry” option from the “**jpos.xml**”.
2. Modify the jpos.xml based on your COM Port
3. Example of jpos.xml file content

```
<?xml version="1.0" encoding="UTF-8"?>
<!DOCTYPE JposEntries PUBLIC "-//JavaPOS//DTD//EN"
           "jpos/res/jcl.dtd">
<JposEntries>
<!--Saved by JavaPOS jpos.config/loader (JCL) version 2.2.0 on 2010/3/11 10:16-->

<JposEntry logicalName="Z3172P">
    <creation factoryClass="com.zbt.jpos.ZbtJposServiceInstanceFactory"
serviceClass="com.zbt.jpos.ScannerService"/>
    <vendor name="" url="" />
    <jpos category="Scanner" version="1.7" />
    <product description="Scanners" name="Scanner" url="" />

    <!--Other non JavaPOS required property (mostly vendor properties and bus specific
properties i.e. RS232 )-->
    <prop name="deviceType" type="String" value="2D" />
    <prop name="deviceBus" type="String" value="RS232" />
    <prop name="baudRate" type="String" value="9600" />
    <prop name="parity" type="String" value="None" />
    <prop name="portName" type="String" value=" COM1" />
    <prop name="flowControl" type="String" value="None" />
    <prop name="stopBits" type="String" value="1" />
    <prop name="dataBits" type="String" value="8" />
</JposEntry>

<?xml version="1.0" encoding="UTF-8"?>
<!DOCTYPE JposEntries PUBLIC "-//JavaPOS//DTD//EN"
           "jpos/res/jcl.dtd">
<JposEntries>

</JposEntries>
```

Note: The default baud rate : 2D scanner =9600


How to use USB scanner with JavaPOS Driver

Configuring the Scanner via barcodes:

- Scan the barcodes in the sequence below to configure the scanner to usb-serial mode.

JavaPOS configuration bar codes:

Set




USB Virtual COM Port



JPOS Enable



End



Install the Java RXTXcomm API

In the \RXTXcomm folder, there are four files: rtxSerial.dll , rtxParallel.dll, and RXTXcomm.jar. Please do the following steps to install the library.

1. Copy rtxSerial.dll and rtxParallel.dll to C:\Windows\system32
2. Copy RXTXcomm.jar to your <JRE Install Folder>\lib directory.

Running the JavaPOS Test utility

Please run the test application to evaluate your installation.

How to Use JavaPOS Driver at your application

1. In the “\Driver” folder, copy “**ZbtJavaPos.jar**” and “**jpos.xml**” to your work folder.
2. Modify the jpos.xml .
3. Example of jpos.xml file content

```
<?xml version="1.0" encoding="UTF-8"?>
<!DOCTYPE JposEntries PUBLIC "-//JavaPOS//DTD//EN"
           "jpos/res/jcl.dtd">
<JposEntries>
<!--Saved by JavaPOS jpos.config/loader (JCL) version 2.2.0 on 2010/3/11 10:16-->

<JposEntry logicalName="Z3172P">
    <creation factoryClass="com.zbt.jpos.ZbtJposServiceInstanceFactory"
serviceClass="com.zbt.jpos.ScannerService"/>
    <vendor name="" url="" />
    <jpos category="Scanner" version="1.7" />
    <product description="Scanners" name="Scanner" url="" />

    <!--Other non JavaPOS required property (mostly vendor properties and bus specific properties i.e.
RS232 )-->
    <prop name="deviceType" type="String" value="2D" />
    <prop name="deviceBus" type="String" value="RS232" />
    <prop name="baudRate" type="String" value="115200" />
    <prop name="parity" type="String" value="None" />
    <prop name="portName" type="String" value=" COM56" />
    <prop name="flowControl" type="String" value="None" />
    <prop name="stopBits" type="String" value="1" />
    <prop name="dataBits" type="String" value="8" />
</JposEntry>

<?xml version="1.0" encoding="UTF-8"?>
<!DOCTYPE JposEntries PUBLIC "-//JavaPOS//DTD//EN"
           "jpos/res/jcl.dtd">
<JposEntries>
</JposEntries>
```