

Programming Guide

Advanced 2D Image Scanner

This Programming Guide is intended for:

- 2D Image Handheld Scanner: Z-3272 Plus

Revision History

Changes to the original manual are listed below:

| Version | Date | Description of Version |
|---------|------------|---|
| 1.0 | 2018/9/12 | Initial release |
| 1.1 | 2021/9/2 | Added FNC1 GS Substitution Values |
| 1.2 | 2021/9/11 | Added new commands for FW210909 |
| 1.3 | 2021/10/19 | Update according to FW211022 change: Customization Gain Level /Mobile phone support for auto scan mode default values changed; deleted Standby Time for Auto Scan Mode |

Important Notice

No warranty of any kind is made in regard to this material, including, but not limited to, implied warranties of merchantability or fitness for any particular purpose. We are not liable for any errors contained herein nor for incidental or consequential damages in connection with furnishing, performance or use of this material. We shall be under no liability in respect of any defect arising from fair wear and tear, willful damage, negligence, abnormal working conditions, failure to follow the instructions and warnings, or misuse or alteration or repair of the products without written approval. No part of this document may be reproduced, transmitted, stored in a retrieval system, transcribed, or translated into any human or computer or other language in any form or by any means electronic, mechanical, magnetic, optical, chemical, biological, manual or otherwise, except for brief passages which may be quoted for purposes of scholastic or literary review, without express written consent and authorization. We reserve the right to make changes in product design without reservation and without notification. The material in this guide is for information only and is subject to change without notice. All trademarks mentioned herein, registered or otherwise, are the properties of their various, ill, assorted owners.

General Handling Precautions

- Do not dispose the scanner in fire.
- Do not put the scanner directly in the sun or by any heat source.
- Do not use or store the scanner in a very humid place.
- Do not drop the scanner or allow it to collide violently with other objects.
- Do not take the scanner apart without authorization

Guidance for Printing

This manual is in A5 size. Please double check your printer setting before printing it out. When the barcodes are to be printed out for programming, the use of a high-resolution laser printer is strongly suggested for the best scan result.

Firmware Notice

To use all functions in this guide please update to the latest firmware.

Copyright © 2021 ZEBEX INDUSTRIES INC. All rights reserved.

Table of Contents

| | |
|---|----|
| Important Notice..... | ii |
| General Handling Precautions..... | ii |
| Guidance for Printing | ii |
| Using the Scanner | 1 |
| Beeper Indication..... | 1 |
| Settings and Programming..... | 2 |
| Program Set Up Flow..... | 2 |
| User Preferences | 3 |
| Show Version..... | 3 |
| System Settings | 3 |
| Customer's Factory Default..... | 4 |
| Scan Mode | 5 |
| Customization Gain Level | 6 |
| Same Code Delay Time for Auto Scan Mode | 8 |
| Interface Switch..... | 9 |
| Mobile Phone Scan Support for Auto Scan Mode..... | 10 |
| Power Up Beep On/ Off..... | 11 |
| Good Read Beep On/ Off..... | 12 |
| Good Read Beep Length..... | 13 |
| Good Read Beep Frequency | 14 |
| Aiming Pattern | 15 |
| Illumination | 16 |
| Terminal Character | 17 |
| RS232 Baud Rate | 18 |
| RS232 Parity Bit..... | 20 |
| RS232 Stop Bit..... | 21 |
| RS232 Data Bit..... | 22 |
| USB Speed | 23 |
| USB Output Speed for USB 1.1..... | 24 |
| Country Code | 27 |
| Persian/Arabic Language Encoding Support..... | 33 |
| Readable Symbologies | 34 |
| All Symbologies | 34 |
| UPC-A | 35 |
| UPC-E..... | 36 |
| EAN-8 | 37 |
| EAN 13..... | 38 |
| Code 128 | 39 |
| Code 39 | 40 |
| Code 93 | 41 |

| | |
|--|----|
| Code 32 | 42 |
| Code 11 | 43 |
| Codabar | 44 |
| Plessey | 45 |
| MSI/Plessey | 46 |
| Interleaved 2 of 5 | 47 |
| IATA 2 of 5 | 48 |
| Matrix 2 of 5..... | 49 |
| Straight 2 of 5..... | 50 |
| RSS 14 (GS1 DATABAR 14) | 51 |
| RSS Expanded (GS1 DATABAR Expanded)..... | 52 |
| RSS Limited (GS1 DATABAR Limited)..... | 53 |
| GS1 DataBar Expanded Stacked | 54 |
| GS1 DataBar 14 Stacked | 55 |
| Component CC-A..... | 56 |
| Component CC-B..... | 57 |
| Component CC-C..... | 58 |
| PDF417 | 59 |
| Micro PDF417..... | 60 |
| Data Matrix | 61 |
| QR Code | 62 |
| Micro QR Code | 63 |
| Aztec..... | 64 |
| MaxiCode | 65 |
| JAPAN POST | 66 |
| Symbology Features | 67 |
| UPC / EAN..... | 67 |
| UPC-A | 68 |
| UPC-A Data Redundant Check..... | 71 |
| UPC-E..... | 72 |
| EAN 8..... | 74 |
| EAN 8 Data Redundant Check | 75 |
| EAN 13..... | 76 |
| Code 39 | 79 |
| Code 39 Data Redundant Check..... | 81 |
| Codabar | 82 |
| Codabar Data Redundant Check | 84 |
| Code 93 Data Redundant Check..... | 85 |
| Code 128 Data Redundant Check..... | 86 |
| Interleaved 2 of 5 | 87 |
| Interleaved 2 of 5 Data Redundant Check..... | 89 |
| MSI / Plessey | 90 |

| | |
|--|------------|
| Code 11 | .92 |
| Data Matrix | .94 |
| QR / Micro QR | .96 |
| Aztec..... | .98 |
| Code 32 (Italian Pharmacode)..... | .99 |
| PDF-417 Data Redundant Check | 100 |
| Matrix 2 of 5..... | 101 |
| Straight 2 of 5 | 102 |
| Japanese Language Encoding Support | 103 |
| JAN code for Books Separator | 104 |
| Data Editing (Prefix) | 106 |
| Prefix Set Up Flow | 106 |
| All Prefix | 107 |
| UPC / EAN Prefix..... | 108 |
| Code 128 Prefix | 110 |
| Code 39 Prefix | 111 |
| Code 93 Prefix | 112 |
| Code 32 Prefix | 113 |
| Code 11 Prefix | 114 |
| Codabar Prefix..... | 115 |
| Plessey Prefix..... | 116 |
| MSI Prefix | 117 |
| Interleaved 2 of 5Prefix | 118 |
| IATA 2 of 5 Prefix | 119 |
| Matrix 2 of 5 Prefix..... | 120 |
| Straight 2 of 5 Prefix..... | 121 |
| RSS 14 Prefix..... | 122 |
| RSS Expanded Prefix | 123 |
| RSS Limited Prefix..... | 124 |
| Component CC-A Prefix..... | 125 |
| Component CC-B Prefix..... | 126 |
| Component CC-C Prefix..... | 127 |
| PDF 417 Prefix | 128 |
| Micro PDF 417 Prefix..... | 129 |
| Data Matrix Prefix | 130 |
| QR Prefix | 131 |
| Micro QR Prefix | 132 |
| Aztec Prefix..... | 133 |
| MaxiCode Prefix | 134 |
| Data Editing (Suffix) | 135 |
| Suffix Set Up Flow..... | 135 |
| All Suffix | 136 |

| | |
|--|-----|
| UPC-A Suffix | 137 |
| UPC-E Suffix..... | 138 |
| EAN 8 Suffix..... | 139 |
| EAN 13 Suffix..... | 140 |
| Code 128 Suffix | 141 |
| Code 39 Suffix | 142 |
| Code 93 Suffix | 143 |
| Code 32 Suffix | 144 |
| Code 11 Suffix | 145 |
| Codabar Suffix..... | 146 |
| Plessey Suffix..... | 147 |
| MSI Suffix | 148 |
| Interleaved 2 of 5 Suffix | 149 |
| IATA 2 of 5 Suffix..... | 150 |
| Matrix 2 of 5 Suffix | 151 |
| Straight 2 of 5 Suffix | 152 |
| RSS 14 Suffix..... | 153 |
| RSS Expanded Suffix | 154 |
| RSS Limited Suffix | 155 |
| Component CC-A Suffix..... | 156 |
| Component CC-B Suffix | 157 |
| Component CC-C Suffix | 158 |
| PDF-417 Suffix | 159 |
| Micro PDF-417 Suffix..... | 160 |
| Data Matrix Suffix..... | 161 |
| QR Code Suffix..... | 162 |
| Micro QR Suffix | 163 |
| Aztec Suffix..... | 164 |
| MaxiCode Suffix | 165 |
| Data Editing (Truncate/Return) | 166 |
| Truncate/Return Commands..... | 166 |
| Set All Symbologies Truncate/Return..... | 167 |
| Set UPC-A Truncate/Return..... | 169 |
| Set UPC-E Truncate/Return | 171 |
| Set EAN-8 Truncate/Return | 173 |
| Set EAN 13 Truncate/Return | 175 |
| Set Code 128 Truncate/Return..... | 177 |
| Set Code 39 Truncate/Return | 179 |
| Set Code 93 Truncate/Return..... | 181 |
| Set Code 32 Truncate/Return..... | 183 |
| Set Code 11 Truncate/Return | 185 |
| Set Codabar Truncate/Return | 187 |

| | |
|---|-----|
| Set Plessey Truncate/Return | 189 |
| Set MSI (Modified Plessy) Truncate/Return | 191 |
| Set Interleaved 2 of 5 Truncate/Return | 193 |
| Interleaved 2 of 5 (ITF).ReturnLeft.4 | 195 |
| Set IATA 2 of 5 Truncate/Return | 196 |
| Set Matrix 2 of 5 Truncate/Return | 198 |
| Set Straight 2 of 5 Truncate/Return | 200 |
| Set RSS 14 (GS1 DataBar) Truncate/Return | 202 |
| Set RSS Expanded (GS1 DataBar Expanded) Truncate/Return | 204 |
| Set RSS Limited (GS1 DataBar Limited) Truncate/Return | 206 |
| Set Component CC-A Truncate/Return | 208 |
| Set Component CC-B Truncate/Return | 210 |
| Set Component CC-C Truncate/Return | 212 |
| Set PDF 417 Truncate/Return | 214 |
| Set Micro PDF 417 Truncate/Return | 216 |
| Set Data Matrix Truncate/Return | 218 |
| Set QR Truncate/Return | 220 |
| Set Micro QR Truncate/Return | 222 |
| Set Aztec Truncate/Return | 224 |
| Set MaxiCode Truncate/Return | 226 |
| Code Settings | 228 |
| Set Lengths for Codes | 228 |
| Set Lengths for Code 128 | 230 |
| Set Lengths for Code 39 | 231 |
| Set Lengths for Code 93 | 232 |
| Set Lengths for Codabar | 233 |
| Set Lengths for Interleaved 2 of 5 | 234 |
| Set Lengths for Code 11 | 235 |
| Set Lengths for MSI | 236 |
| Set Lengths for Matrix 2 of 5 | 237 |
| Code Identifiers | 238 |
| GS1-2D AIM ID | 239 |
| GS1-128 AIM ID | 240 |
| Code Identifiers Table | 241 |
| Keyboard Caps Lock State | 242 |
| FNC1 GS Substitution Values | 244 |
| Function Key Mapping | 245 |
| Function Key Extended | 246 |
| ASCII Code | 247 |
| USB Virtual COM Driver Installing | 268 |
| JavaPOS Setting | 269 |
| JavaPOS | 269 |

| | |
|---|-----|
| JavaPOS Version | 270 |
| Install the Java2 Runtime Environment..... | 270 |
| Install the Service Object and JavaPOS files..... | 270 |
| How to use RS232 scanner with JavaPOS Driver..... | 270 |
| Use barcodes to configure the scanner..... | 271 |
| Running the JavaPOS Test utility | 272 |
| How to use JavaPOS driver at your application..... | 272 |
| How to use USB scanner with JavaPOS Driver | 273 |
| Install the Java RXTXcomm API | 274 |
| Running the JavaPOS Test utility | 274 |
| How to Use JavaPOS Driver at your application | 275 |

Using the Scanner

Beeper Indication

| Beeps | Indication |
|--|---|
| 3 beeps in a series from low to high pitch | Power up |
| 1 short beep | A barcode has been successfully decoded |
| 2 short beeps | The scanner has entered program mode |
| 1 long beep | A setting has been programmed |
| 3 beeps in a series from low to high pitch | The scanner has exited program mode |
| 3 short beeps | Error setting the scanner |

Settings and Programming

Scan selected barcodes in this manual to affect setup and programming of your 2D image barcode scanner. Decoding options and interface protocols can be tailored to a specific application.

Setup parameters are stored in non-volatile memory in the scanner and are retained even when power is off. Setup parameters change only when you reset them. You may need to hide adjacent code patches with your hand when scanning.

Program Set Up Flow

Scan "Set" to set up --> Scan selected barcode --> Scan "End" to confirm the setup.

User Preferences

Show Version

Scan this barcode to display firmware version.




Read device information

System Settings

Scan this barcode to return all parameters to the default values.



Set




Factory default settings



End

Customer's Factory Default

Scan barcodes below to set or delete customer's factory default.




Set



Save customer's factory default



Delete customer's factory default




End

Scan Mode

Scan a barcodes below to set the scanner to different modes.

Trigger Mode: This scanner becomes inactive as soon as the data is transmitted by pressing the trigger button.


Auto Scan Mode: The scanner is still active after the data is transmitted but the successive transmission of the same code is not allowed.




Set



Trigger Mode (Default)




Auto Scan Mode



End

Customization Gain Level

Set gain level for captured image quality. When the light is low, the higher gain level can enhance the captured image quality for better scanning performance.



Set



Level 1 (Low)



Level 2




Level 3



Level 4




Level 5




End




Set




Level 7



Level 9



End



Level 6




Level 8 (Default)



Level 10 (High)

Same Code Delay Time for Auto Scan Mode

Scan a barcode below to select the duration of the delay time for Auto Scan Mode.



Set




500 msec (Default)




1 sec



1.5 sec



2 sec




End

Interface Switch


Your 2D Imager supports interfaces such as USB HID, RS232 serial, and USB virtual COM. To switch the interface, simply select the appropriate cable and configure the proper interface by following interface selection.




Set



RS-232



USB Keyboard



USB Virtual COM Port


*Driver required



End

Mobile Phone Scan Support for Auto Scan Mode

Enable or disable mobile phone scan support..




Set



Enable (Default)




Disable



End

Power Up Beep On/ Off

Scan a barcode below to turn on/off power up beep.



Set



On (Default)




Off



End

Good Read Beep On/ Off

Scan a barcode below to turn on/off good read beep.




Set



Off




On (Default)




End

Good Read Beep Length

Scan a barcode below to select the duration of the beep signal after a good decode.



Set



100 msec




50 msec (Default)



150 msec



200 msec



End

Good Read Beep Frequency

Scan a barcode below to select the beep tone of the beep signal after a good decode.



Set



Low



Medium (Default)



High



End

Aiming Pattern


Aiming pattern works as an aiming system to aid in barcode reading. Use the following settings to enable or disable this function. This function is for supporting models only.



Set



Auto (Default)



Always On



Always Off



End

Illumination

Set Illumination to aid in barcode reading. Use the following settings to configure this function.



Set



On (Default)



Always On




Off




End

Terminal Character


Set




None



(V-COM & RS-232 Default)



(HID Default)



TAB



LF




End

RS232 Baud Rate


Baud rate is the number of bits of data transmitted per second. Set the imager's baud rate to match the baud rate setting of the host device. Otherwise, data may not reach the host device or may reach it in distorted form.




Set




9600 (Default)




19200



38400




57600




End



Set



115200




230400



End

RS232 Parity Bit


Parity bit can be added to ensure the total number of the string is even or odd.



Set



None (Default)



Even parity




Odd parity



End

RS232 Stop Bit

Stop bit is used to signal the end of a transmission.




Set



1 Stop Bit (Default)



2 Stop Bit



End

RS232 Data Bit

Data bit sets the word length at 7 or 8 bits of data per character.




Set



CS7



CS8 (Default)




End

USB Speed

Scan a barcode below to set USB speed.




Set



USB 1.1 (Default)




USB 2.0



End

USB Output Speed for USB 1.1

Scan a barcode below to set USB 1.1 output speed.




Set




1 (Fastest)



2




3




4




5



End



Set




6



7



8




9




10 (Default)



End



Set



11



12



13




14



15




16 (Slowest)



End

Country Code


Scann the following settings to change the country code.



Set




US (Default)




Belgium




Britain




Denmark




End



Set



France




Germany




Italy



Norway




End



Set



Portugal



Spain




Sweden




Switzerland




End



Set




Japan




Hungary




Czech Republic



Slovakia




End



Set




Romania



Croatia



Poland



Finland




United Kingdom



Russia



End



Set




International Keyboard mode
(ALT mode)



Turkey-Q




Turkey-F



End

Persian/Arabic Language Encoding Support

Scann the following settings to change the encoding options.



Set



ISO 8859-6



End



UTF-8 (Default)



CP1256 (WINDOWS-1256)

Readable Symbologies

This section provides the programming barcodes for enabling and disabling readable symbologies. If the default values suit requirements, programming is not necessary.

All Symbologies



Set




Enable All



Default



End

UPC-A

Set



Enable UPC-A (Default)



Disable UPC-A



End

UPC-E



Set



Enable UPC-E



Disable UPC-E (Default)



End

EAN-8

Set



Enable EAN 8 (Default)



Disable EAN 8



End

EAN 13



Set



Disable EAN 13



Enable EAN 13 (Default)



End

Code 128

Set



Disable Code 128




Enable Code 128 (Default)



End

Code 39



Set



Disable Code 39



Enable Code 39 (Default)




End

Code 93

Set



Disable Code 93



Enable Code 93 (Default)




End

Code 32



Set



Enable Code 32



Disable Code 32 (Default)



End

Code 11

Set



Enable Code 11




Disable Code 11 (Default)



End

Codabar



Set



Enable Codabar (Default)



Disable Codabar



End

Plessey

Set



Enable Plessey



Disable Plessey (Default)



End

MSI/Plessy



Set



Enable MSI/Plessy



Disable MSI/Plessy (Default)



End

Interleaved 2 of 5


Set



Enable Interleaved 2 of 5 (Default)



Disable Interleaved 2 of 5



End

IATA 2 of 5



Set



Enable IATA 2 of 5



Disable IATA 2 of 5 (Default)



End

Matrix 2 of 5


Set



Enable Matrix 2 of 5



Disable Matrix 2 of 5 (Default)



End

Straight 2 of 5



Set



Enable Straight 2 of 5



Disable Straight 2 of 5 (Default)



End

RSS 14 (GS1 DATABAR 14)


Set



Enable RSS 14 (Default)




Disable RSS 14



End

RSS Expanded (GS1 DATABAR Expanded)



Set



Enable RSS Expanded (Default)



Disable RSS Expanded



End

RSS Limited (GS1 DATABAR Limited)

Set



Enable RSS Limited (Default)



Disable RSS Limited



End


GS1 DataBar Expanded Stacked




Set



Enable



Disable (Default)




End

GS1 DataBar 14 Stacked


Set



Enable




Disable (Default)



End

Component CC-A



Set



Enable Component CC-A



Disable Component CC-A (Default)



End

Component CC-B


Set



Enable Component CC-B



Disable Component CC-B (Default)



End

Component CC-C



Set



Enable Component CC-C



Disable Component CC-C (Default)



End

PDF417

Set



Enable PDF417 (Default)




Disable PDF417



End

Micro PDF417




Set



Enable Micro PDF417 (Default)



Disable Micro PDF417



End

Data Matrix



Set



Enable Data Matrix (Default)



Disable Data Matrix




End

QR Code



Set



Enable QR Code (Default)



Disable QR Code




End


Micro QR Code



Set



Enable Micro QR Code (Default)



Disable Micro QR Code



End

Aztec



Set



Enable Aztec



Disable Aztec (Default)



End

MaxiCode


Set



Enable MaxiCode



Disable MaxiCode (Default)



End

JAPAN POST



Set



Enable



Disable(Default)



Check Digit Enable(Default)



Check Digit Disable



END

Symbology Features

This section provides the programming barcodes for selecting features available to different symbologies.

UPC / EAN




Set



Enable decoding of 2/5-digit supplemental code for UPC-A, UPC-E, EAN-13, and EAN-8




Disable decoding of 2/5-digit supplemental code for UPC-A, UPC-E, EAN-13, and EAN-8 (Default)




End


UPC-A




Set




Enable UPC-A Number System digit
(Default)



Disable UPC-A Number System digit



Enable UPC-A check digit (Default)




Disable UPC-A check digit





End




Set




Enable conversion of UPC-A to EAN13

Disable conversion of UPC-A to EAN13
(Default)

Enable Leading Character




Disable Leading Character (Default)



End




Set




Enable UPC-A clear leading zero



Disable UPC-A clear leading zero (Default)



End

UPC-A Data Redundant Check

Set



Off (Default)




1



2




3




End


UPC-E




Set




Enable UPC-E Number System digit
(Default)




Disable UPC-E Number System digit



Enable UPC-E check digit (Default)




Disable UPC-E check digit




End




Set



Enable conversion of UPC-E to UPC-A

Disable conversion of UPC-E to UPC-A
(Default)

Enable UPC-E clear leading zero


Disable UPC-E clear leading zero
(Default)

End


EAN 8




Set




Disable EAN 8 check digit



Disable conversion of EAN 8 to EAN 13
(Default)




Enable EAN 8 check digit (Default)



Enable conversion of EAN 8 to EAN 13



End

EAN 8 Data Redundant Check

Set



Off (Default)




1



2




3




End


EAN 13



Set




Enable EAN 13 check digit (Default)




Disable EAN 13 check digit



Enable conversion of EAN 13 to ISBN




Disable conversion of EAN 13 to ISBN
(Default)




End



Set



Enable conversion of EAN 13 to ISSN

Disable conversion of EAN 13 to ISSN
(Default)

End




Set



EAN 13 data redundant check = off




EAN 13 data redundant check = 1
(Default)



EAN 13 data redundant check = 2




EAN 13 data redundant check = 3




End

Code 39


Set




Disable Code 39 full ASCII mode (Default)



Enable Code 39 full ASCII mode



Disable Start and Stop characters (Default)




Enable Start and Stop characters




End




Set



Disable Checksum (Default)




Enable checksum and send check
character



Enable checksum and strip check
character



End

Code 39 Data Redundant Check

Set



Off (Default)




1



2




3




End

Codabar



Set



Disable Checksum (Default)



Enable checksum and send check
character



Enable checksum and strip check
character




End



Set



Enable stripping Start and Stop characters

Disable stripping Start and Stop characters
(Default)

End

Codabar Data Redundant Check



Set



Off



1




2 (Default)



3



End

Code 93 Data Redundant Check

Set



Off (Default)



1



2




3



End

Code 128 Data Redundant Check



Set



Off



1



2 (Default)




3




End

Interleaved 2 of 5


Set




Enable checksum and send check character



Disable Checksum (Default)




Enable checksum and strip check character




End




Set



Default quiet zone checking
No length checking performed (Default)



Smaller quiet zone allowed



End

Interleaved 2 of 5 Data Redundant Check

Set



Off (Default)




1



2



3




End


MSI / Plessey




Set




Disable MSI Plessey checksum




Mod 10 checksum (Default)



Mod 10/10 checksum




Mod 11/10 checksum




End




Set



Output checksum character(s) (Default)



Strip checksum character(s)




End


Code 11




Set



Output checksum character(s)




Strip checksum character(s) (Default)



End




Set



Disable checksum checking



Enable 1-digit checksum checking

Enable 2-digit checksum checking
(Default)

End

Data Matrix



Set



Disable mirror decoding



Enable mirror decoding (Default)





End



Set



Enable rectangular Data Matrix decoding


Disable rectangular Data Matrix decoding
(Default)

End


QR / Micro QR




Set




Disable mirror decoding



Enable mirror decoding (Default)



End



Set



UTF8 conversion for word only




Universal UTF8 conversion (Default)




End

Note: Please install QR_UTF8_Conversion executable file before using this function.


Aztec




Set



Disable mirror decoding



Enable mirror decoding (Default)



End

Code 32 (Italian Pharmacode)

Set




Transmit

Alphabet "A" char




Disable Transmit
Alphabet "A" char
(Default)



End

PDF-417 Data Redundant Check



Set



Off (Default)



1



2



3




End

Matrix 2 of 5

Set



Disable Checksum (Default)

Enable checksum and send check
characterEnable checksum and strip check
character

End

Straight 2 of 5



Set




Disable Checksum (Default)



Enable checksum and send check
character



Enable checksum and strip check
character



End

Japanese Language Encoding Support




Set



Enable



Disable (Default)



End

JAN code for Books Separator



Set



[TAB] key x 2



[SPACE] key x 3



Others char Separator

For parameters requiring specific numeric values, scan the [PROGRAMMING GUIDE\ASCII Code] appropriately numbered barcode(s).



End



Set



None (Default)



End

Data Editing (Prefix)

Prefix is additional characters that can be sent before the scanned data. Please scan the barcodes in the selection below to set your prefix.


Prefix Set Up Flow

1. Scan Set.
2. Enable barcode type.
3. Scan prefix you would like to add characters within ASCII Table. Up to 4 digits can be added.
4. Scan End.


Ex. If we wish to add “3” as prefix for all barcode type, then follow procedure as below, Scan [Set] to enter setup. Then we select barcode by scanning [Enable All], then we scan [3] as 3 of ASCII HEX. At the end, we scan [End] to completed setup.

All Prefix

Set



Enable All




Disable All (Default)




End


UPC / EAN Prefix




Set



Disable UPC-A



Disable UPC-E




Enable UPC-A




Enable UPC-E




End




Set




Disable EAN 8



Enable EAN 8



Disable EAN 13




Enable EAN 13




End


Code 128 Prefix



Set



Enable Code 128




Disable Code 128




End

Code 39 Prefix

Set



Disable Code 39




Enable Code 39



End


Code 93 Prefix



Set



Enable Code 93



Disable Code 93




End


Code 32 Prefix



Set



Disable Code 32




Enable Code 32




End


Code 11 Prefix



Set



Enable Code 11



Disable Code 11




End


Codabar Prefix



Set



Disable Codabar



Enable Codabar




End


Plessey Prefix



Set




Disable Plessey




Enable Plessey




End

MSI Prefix

Set



Disable MSI



Enable MSI




End


Interleaved 2 of 5 Prefix



Set



Enable Interleaved 2 of 5




Disable Interleaved 2 of 5



End

IATA 2 of 5 Prefix


Set



Enable IATA 2 of 5



Disable IATA 2 of 5




End


Matrix 2 of 5 Prefix



Set



Enable Matrix 2 of 5




Disable Matrix 2 of 5




End

Straight 2 of 5 Prefix

Set



Disable Straight 2 of 5



Enable Straight 2 of 5




End


RSS 14 Prefix



Set



Disable RSS 14



Enable RSS 14



End


RSS Expanded Prefix



Set



Disable RSS Expanded



Enable RSS Expanded




End


RSS Limited Prefix



Set



Disable RSS Limited




Enable RSS Limited




End

Component CC-A Prefix

Set



Disable Component CC-A



Enable Component CC-A



End

Component CC-B Prefix



Set



Disable Component CC-B




Enable Component CC-B




End

Component CC-C Prefix

Set



Disable Component CC-C



Enable Component CC-C



End


PDF 417 Prefix



Set



Disable PDF 417



Enable PDF 417



End

Micro PDF 417 Prefix

Set



Disable Micro PDF 417



Enable Micro PDF 417



End

Data Matrix Prefix



Set



Disable Data Matrix



Enable Data Matrix




End

QR Prefix

Set



Disable QR Code



Enable QR Code




End


Micro QR Prefix



Set



Disable Micro QR



Enable Micro QR



End


Aztec Prefix



Set



Disable Aztec



Enable Aztec



End

MaxiCode Prefix



Set



Disable Maxicode



Enable Maxicode



End

Data Editing (Suffix)

Suffix is additional characters that can be sent after the scanned data. Please scan the barcodes in the selection below to set your suffix.

Suffix Set Up Flow


1. Scan Set.
2. Enable barcode type.
3. Scan suffix you would like to add characters within ASCII Table. Up to 4 digits can be added.
4. Scan End.

Ex. If we wish to add “36” as suffix for all barcode type, then follow procedure as below. Scan [Set] to enter setup. Then we select barcode by scanning [Enable All], then we scan [3] as 3 of ASCII HEX and [6] as 6.


All Suffix




Set



Disable All (Default)




Enable All




End

UPC-A Suffix

Set



Disable UPC-A



Enable UPC-A




End


UPC-E Suffix



Set



Disable UPC-E



Enable UPC-E




End

EAN 8 Suffix

Set



Disable EAN 8



Enable EAN 8




End

EAN 13 Suffix



Set



Disable EAN 13




Enable EAN 13




End

Code 128 Suffix

Set



Disable Code 128



Enable Code 128



End


Code 39 Suffix



Set



Disable Code 39



Enable Code 39



End


Code 93 Suffix



Set



Disable Code 93



Enable Code 93




End


Code 32 Suffix



Set



Disable Code 32



Enable Code 32




End

Code 11 Suffix

Set



Disable Code 11



Enable Code 11




End


Codabar Suffix



Set



Disable Codabar



Enable Codabar




End


Plessey Suffix



Set



Disable Plessey



Enable Plessey




End


MSI Suffix



Set



Disable MSI



Enable MSI




End

Interleaved 2 of 5 Suffix

Set



Disable Interleaved 2 of 5



Enable Interleaved 2 of 5




End

IATA 2 of 5 Suffix




Set



Disable IATA 2 of 5



Enable IATA 2 of 5



End

Matrix 2 of 5 Suffix

Set



Disable Matrix 2 of 5



Enable Matrix 2 of 5



End

Straight 2 of 5 Suffix



Set



Disable Straight 2 of 5



Enable Straight 2 of 5



End


RSS 14 Suffix



Set



Disable RSS 14



Enable RSS 14




End


RSS Expanded Suffix



Set



Disable RSS Expanded



Enable RSS Expanded



End

RSS Limited Suffix

Set



Disable RSS Limited



Enable RSS Limited




End

Component CC-A Suffix



Set



Disable Component CC-A




Enable Component CC-A



End

Component CC-B Suffix

Set



Disable Component CC-B



Enable Component CC-B



End


Component CC-C Suffix



Set



Disable Component CC-C



Enable Component CC-C



End


PDF-417 Suffix



Set



Disable PDF417



Enable PDF417




End

Micro PDF-417 Suffix



Set



Disable Micro PDF417



Enable Micro PDF417



End

Data Matrix Suffix



Set



Data Matrix Disable



Data Matrix Enable




End


QR Code Suffix



Set



QR Code Disable



QR Code Enable



End


Micro QR Suffix



Set



Micro QR Disable



Micro QR Enable




End


Aztec Suffix



Set



Aztec Disable



Aztec Enable



End


MaxiCode Suffix



Set



MaxiCode Disable



MaxiCode Enable



End


Data Editing (Truncate/Return)

Truncate/Return Commands

- Return the leftmost characters: Specify the number of leftmost characters you want returned.
- Truncate the leftmost characters: Specify the number of leftmost characters you want deleted.
- Return the Rightmost characters: Specify the number of rightmost characters you want returned.
- Truncate the Rightmost characters: Specify the number of rightmost characters you want deleted.
- Return the Middle characters: Returns the middle characters. The middle is found by scanning from left to right, and parameters determine where the middle begins and ends
- Truncate the Middle characters: Delete the middle characters. The middle is found by scanning from left to right, and parameters determine where the middle begins and ends

Set Up Flow

1. Scan Set to set up
2. Enable barcode type
3. Scan one of Truncate/Return Command
4. Select lengths using the numeric bar codes in ASCII Code Table
5. Scan End

Set All Symbologies Truncate/Return

Set



Return leftmost




Truncate leftmost




Return rightmost



Truncate rightmost



End



Set




Return middle




Truncate middle



Disable All (Default)



End

Set UPC-A Truncate/Return

Set



Return leftmost




Truncate leftmost




Return rightmost




Truncate rightmost



End



Set




Return middle




Truncate middle



Disable (Default)



End

Set UPC-E Truncate/Return

Set



Return leftmost




Truncate leftmost




Return rightmost



Truncate rightmost



End



Set




Return middle




Truncate middle



Disable (Default)



End

Set EAN-8 Truncate/Return

Set



Return leftmost




Truncate leftmost




Return rightmost



Truncate rightmost



End



Set




Return middle




Truncate middle



Disable (Default)



End

Set EAN 13 Truncate/Return

Set



Return leftmost




Truncate leftmost




Return rightmost



Truncate rightmost



End



Set



Return middle




Truncate middle



Disable (Default)



End

Set Code 128 Truncate/Return

Set



Return leftmost




Truncate leftmost




Return rightmost



Truncate rightmost



End



Set




Return middle



Truncate middle



Disable (Default)



End

Set Code 39 Truncate/Return

Set



Return leftmost




Truncate leftmost




Return rightmost



Truncate rightmost



End



Set



Return middle




Truncate middle



Disable (Default)



End

Set Code 93 Truncate/Return

Set



Return leftmost




Truncate leftmost




Return rightmost



Truncate rightmost



End



Set




Return middle




Truncate middle



Disable (Default)



End

Set Code 32 Truncate/Return

Set



Return leftmost




Truncate leftmost




Return rightmost



Truncate rightmost



End



Set




Return middle




Truncate middle



Disable (Default)



End

Set Code 11 Truncate/Return

Set



Return leftmost




Truncate leftmost




Return rightmost



Truncate rightmost



End



Set




Return middle




Truncate middle



Disable (Default)



End

Set Codabar Truncate/Return

Set



Return leftmost




Truncate leftmost




Return rightmost



Truncate rightmost



End



Set




Return middle




Truncate middle



Disable (Default)



End

Set Plessey Truncate/Return

Set



Return leftmost




Truncate leftmost




Return rightmost



Truncate rightmost



End



Set




Return middle




Truncate middle



Disable (Default)



End

Set MSI (Modified Plessy) Truncate/Return

Set



Return leftmost




Truncate leftmost




Return rightmost



Truncate rightmost



End



Set




Return middle




Truncate middle



Disable (Default)



End

Set Interleaved 2 of 5 Truncate/Return

Set



Return leftmost




Truncate leftmost




Return rightmost



Truncate rightmost



End



Set




Return middle



Truncate middle



Disable (Default)



End


Interleaved 2 of 5 (ITF).ReturnLeft.4

Disable (default)



Enable

Set IATA 2 of 5 Truncate/Return



Set



Return leftmost



Truncate leftmost




Return rightmost



Truncate rightmost



End



Set




Return middle



Truncate middle




Disable (Default)



End

Set Matrix 2 of 5 Truncate/Return



Set



Return leftmost




Truncate leftmost




Return rightmost



Truncate rightmost



End



Set




Return middle



Truncate middle




Disable (Default)



End

Set Straight 2 of 5 Truncate/Return



Set



Return leftmost




Truncate leftmost




Return rightmost



Truncate rightmost



End



Set




Return middle



Truncate middle




Disable (Default)



End

Set RSS 14 (GS1 DataBar) Truncate/Return



Set



Return leftmost




Truncate leftmost




Return rightmost



Truncate rightmost



End



Set




Return middle



Truncate middle




Disable (Default)



End

Set RSS Expanded (GS1 DataBar Expanded) Truncate/Return



Set



Return leftmost




Truncate leftmost




Return rightmost



Truncate rightmost



End



Set




Return middle



Truncate middle




Disable (Default)



End

Set RSS Limited (GS1 DataBar Limited) Truncate/Return



Set



Return leftmost



Truncate leftmost




Return rightmost



Truncate rightmost



End



Set




Return middle



Truncate middle




Disable (Default)



End

Set Component CC-A Truncate/Return



Set



Return leftmost




Truncate leftmost



Return rightmost



Truncate rightmost



End



Set




Return middle



Truncate middle



Disable (Default)



End

Set Component CC-B Truncate/Return



Set



Return leftmost




Truncate leftmost




Return rightmost



Truncate rightmost



End



Set




Return middle



Truncate middle




Disable (Default)



End

Set Component CC-C Truncate/Return



Set



Return leftmost




Truncate leftmost




Return rightmost



Truncate rightmost



End



Set




Return middle



Truncate middle




Disable (Default)



End

Set PDF 417 Truncate/Return



Set



Return leftmost




Truncate leftmost




Return rightmost



Truncate rightmost



End



Set




Return middle



Truncate middle




Disable (Default)



End

Set Micro PDF 417 Truncate/Return



Set



Return leftmost



Truncate leftmost




Return rightmost



Truncate rightmost



End



Set




Return middle



Truncate middle




Disable (Default)



End

Set Data Matrix Truncate/Return



Set



Truncate leftmost




Truncate rightmost




Return leftmost



Return rightmost



End



Set




Return middle



Truncate middle




Disable (Default)



End

Set QR Truncate/Return



Set



Return leftmost




Truncate leftmost




Return rightmost



Truncate rightmost



End



Set




Return middle



Truncate middle




Disable (Default)



End

Set Micro QR Truncate/Return



Set



Return leftmost




Truncate leftmost




Return rightmost



Truncate rightmost



End



Set




Return middle



Truncate middle




Disable (Default)



End

Set Aztec Truncate/Return



Set



Return leftmost



Truncate leftmost




Return rightmost



Truncate rightmost



End



Set




Return middle



Truncate middle




Disable (Default)



End

Set MaxiCode Truncate/Return



Set



Return leftmost




Truncate leftmost




Return rightmost



Truncate rightmost



End



Set




Return middle



Truncate middle



Disable (Default)



End

Code Settings

Set Lengths for Codes

- One Discrete Length

Select this option to decode the symbol containing a selected length.
Select the length using the numeric bar codes in ASCII Code Table.

Example 1:

To decode Interleaved 2 of 5 symbols with 8 characters:

- a. scan Set to set up
- b. scan Interleaved 2 of 5 One Discrete Length
- c. scan 8 in ASCII Code Table
- d. scan End to confirm the setup

Example 2:

To decode Interleaved 2 of 5 symbols with 12 characters:

- a. scan Set to set up
- b. scan Interleaved 2 of 5 One Discrete Length
- c. scan scan 1 followed by 2 in ASCII Code Table
- d. scan End to confirm the setup

- Two Discrete Lengths

Select this option to decode the symbol containing either of two selected lengths.
Select lengths using the numeric bar codes in ASCII Code Table.

Example:

To decode Code 128 symbols containing either 8 or 14 characters

- a. scan Set to set up
- b. scan Code 128 Two Discrete Length
- c. scan 0, 8, 1, and then 4 in ASCII Code Table
- d. scan End to confirm the setup

- Length Within Range

Select this option to decode the symbol with a specific length range.
Select lengths using numeric bar codes in ASCII Code Table.

Example:

- To decode Codabar symbols containing between 7 and 8 characters,
- a. scan Set to set up
 - b. scan Codabar Length Within Range
 - c. scan 0, 7, 0, and then 8 in ASCII Code Table
 - d. scan End to confirm the setup


- Any Length

Select this option to decode the symbol containing any number of characters within the digital scanner's capability.

Example:

- a. scan Set to set up
- b. scan Matrix 2 of 5 Any Length
- c. scan End to confirm the setup

Set Lengths for Code 128



Set



One Discrete Length




Two Discrete Lengths



Length Within Range




Any Length (Default)



End

Set Lengths for Code 39




Set




One Discrete Length




Two Discrete Lengths



Length Within Range




Any Length (Default)



End

Set Lengths for Code 93



Set



One Discrete Length




Two Discrete Lengths



Length Within Range




Any Length (Default)




End

Set Lengths for Codabar



Set



One Discrete Length




Two Discrete Lengths



Length Within Range




Any Length (Default)



End

Set Lengths for Interleaved 2 of 5



Set



One Discrete Length




Two Discrete Lengths



Length Within Range




Any Length (Default)



End

Set Lengths for Code 11



Set



One Discrete Length




Two Discrete Lengths



Length Within Range




Any Length (Default)




End


Set Lengths for MSI



Set



One Discrete Length




Two Discrete Lengths




Length Within Range



Any Length (Default)




End

Set Lengths for Matrix 2 of 5

Set




One Discrete Length




Two Discrete Lengths



Length Within Range




Any Length (Default)



End

Code Identifiers

Scan the following barcodes to set symbology Identifiers.




Set




Disable Code ID (Default)



Enable factory standard ID



Enable AIM ID



End

GS1-2D AIM ID

GS1 2D barcodes (GS1 DataMatrix, GS1 QR Code) output AIM ID Setting.




Set



Enable



Disable (Default)



End

GS1-128 AIM ID

GS1-128 output AIM ID Setting.




Set



Enable



Disable (Default)



End

Code Identifiers Table


| Symbology | Factory Standard | AIM |
|--|------------------|-----|
| UPC-A | A |]E |
| UPC-E | E |]E |
| EAN 8 | FF |]E |
| EAN 13 | F |]E |
| Code 128 | K |]C |
| Code 39 | M |]A |
| Code 93 | L |]G |
| Code 32 | M |]X |
| Code 11 | O |]H |
| Codabar | N |]F |
| Plessey | P |]P |
| MSI / Plessey | a |]M |
| Interleaved 2 of 5 | I |]I |
| IATA 2 of 5 | Z |]R |
| Matrix 2 of 5 | G |]X |
| Straight 2 of 5 | S |]S |
| Pharmacode | H |]X |
| RSS 14 (GS1 DATABAR 14) | RS |]e |
| RSS Expanded (GS1 DataBar Expanded) | RX |]e |
| RSS Limited (GS1 DataBar Limited) | RL |]e |
| Component CC-A | m |]e |
| Component CC-B | n |]e |
| Component CC-C | i |]e |
| PDF417 | r |]L |
| Micro PDF417 | s |]L |
| Data Matrix | t |]d |
| QR | u |]Q |
| Micro QR | j |]Q |
| Aztec | e |]z |
| MaxiCode | v |]U |
| RSS 14 | RS |]e |
| RSS Expanded | RX |]e |

Keyboard Caps Lock State

Scan a barcode below to turn Caps on or off.



Set




Caps Lock Off (Default)



Caps Lock On




End




Set




Alphabet always upper case



Alphabet always Lower case



Override



End

FNC1 GS Substitution Values




Set



“Ctrl+]” (Default)




“Alt+29(KP)”
(nmvs)



End

Function Key Mapping

Scan the following barcodes to enable or disable Function Key Mapping.




Set



Disable Function Key Mapping (Default)




Enable Function Key Mapping



End

Function Key Extended

Scan the following barcodes to enable or disable Function Key Extended. Enable Function Key Extended change the Function Key from [Left-CTRL] to [Right-CTRL].




Set



Disable Function Key Extended (Default)



Enable Function Key Extended



End

ASCII Code


For parameters requiring specific numeric values, scan the appropriately numbered barcode(s).




Space




!




"



#




\$




%




&



!




(









)




*




+







<




=



>




?




@




Enter




0




1




2




3




4




5




6




7



8




9




A

(Function Key
Mapping: Ctrl+a)




B

(Function Key
Mapping: Ctrl+b)




C

(Function Key
Mapping: Ctrl+c)




D

(Function Key
Mapping: Ctrl+d)




E

(Function Key
Mapping: Ctrl+e)




F

(Function Key
Mapping: Ctrl+f)




G

(Function Key
Mapping: Ctrl+g)




H

(Function Key
Mapping: Ctrl+h)




I

(Function Key
Mapping: Ctrl+i)




J

(Function Key
Mapping: Ctrl+j)




K

(Function Key
Mapping: Ctrl+k)




L


(Function Key
Mapping: Ctrl+l)




M
(Function Key
Mapping: Ctrl+m)




N
(Function Key
Mapping: Ctrl+n)




O
(Function Key
Mapping: Ctrl+o)



P
(Function Key
Mapping: Ctrl+p)




Q
(Function Key
Mapping: Ctrl+q)




R

(Function Key
Mapping: Ctrl+r)




S

(Function Key
Mapping: Ctrl+s)




T

(Function Key
Mapping: Ctrl+t)




U

(Function Key
Mapping: Ctrl+u)




V

(Function Key
Mapping: Ctrl+v)




W

(Function Key
Mapping: Ctrl+w)




X

(Function Key
Mapping: Ctrl+x)




Y

(Function Key
Mapping: Ctrl+y)




Z


(Function Key
Mapping: Ctrl+z)




a



b




c




d




e




f




g




h




i




j




k




l




m




n




o




p




q




r




S




T




U




V




W



X



Y



Z



Insert



Delete



Home



End



Up arrow



Down arrow



Left arrow



Right arrow



Tab



Backspace



Shift



ESC



Page up



Page down



Ctrl



Alt




SOH



ETX



F1



F2



F3



F4



F5




F6




F7



F8



F9



F10



F11




F12

USB Virtual COM Driver Installing

If you use virtual COM port emulation, follow the steps below to start using the scanner.

1. Execute the driver (ZEBEX VCOM Driver Installation.exe).
2. Connect the scanner USB cable to the host computer.
3. Set the interface to USB Virtual COM Port.




Set



USB Virtual COM Port

*Driver required



End

4. On the computer, check Device Manager to see if the computer successfully detects the scanner as “Barcode Scanner USB-COM device.” (The COM port number would vary depending on different hardware environment).




JavaPOS Setting

This section provides the programming barcodes for setting JavaPOS and the flow of installing JavaPOS driver.

JavaPOS

Scan the following barcodes to enable or disable JavaPOS.




Set



JPOS Enable



JPOS Disable (Default)



End

JavaPOS Version

Our JavaPOS driver now is compatible with JavaPOS1.7.

Install the Java2 Runtime Environment

The JRE is Java's virtual machine that allows for applications to run on the host computer. To be able to run the JavaPOS application, you need a 1.7 version JRE. Ignore the following steps if you already have a JavaPOS1.7 or a later version in your host computer.

- Go to <http://java.sun.com>, and select this version of Java Runtime Environment.
- Install the program following the instructions.

Install the Service Object and JavaPOS files

In the “\Driver” folder, there are two files: ZbtJavapos.jar and jpos.xml. Please include ZbtJavapos.jar at your CLASSPATH and also copy the related “JPosEntry” option from the jpos.xml to your application’s jpos.xml.

How to use RS232 scanner with JavaPOS Driver

Install the Java RXTXcomm API


In the \RXTXcomm folder, there are four files: rtxSerial.dll , rtxParallel.dll, and RXTXcomm.jar. Please do the following steps to install the library.

1. Copy rtxSerial.dll and rtxParallel.dll to C:\Windows\system32.
2. Copy RXTXcomm.jar to your <JRE Install Folder>\lib directory.

Use barcodes to configure the scanner

JavaPOS configuration barcodes:


Set




RS-232



JPOS Enable



End



Running the JavaPOS Test utility

Please run the test application POStest.sh to evaluate your installation.

How to use JavaPOS driver at your application

1. Add “ZbtJavaPos.jar” from the “\Driver” folder to the CLASSPATH and copy the related “JPosEntry” option from the “**jpos.xml**”.
2. Modify the jpos.xml based on your COM Port
3. Example of jpos.xml file content

```
<?xml version="1.0" encoding="UTF-8"?>
<!DOCTYPE JposEntries PUBLIC "-//JavaPOS//DTD//EN"
           "jpos/res/jcl.dtd">
<JposEntries>
<!--Saved by JavaPOS jpos.config/loader (JCL) version 2.2.0 on 2010/3/11 10:16-->

<JposEntry logicalName="Z3172P">
    <creation factoryClass="com.zbt.jpos.ZbtJposServiceInstanceFactory"
serviceClass="com.zbt.jpos.ScannerService"/>
    <vendor name="" url="" />
    <jpos category="Scanner" version="1.7" />
    <product description="Scanners" name="Scanner" url="" />

    <!--Other non JavaPOS required property (mostly vendor properties and bus specific
properties i.e. RS232 )-->
    <prop name="deviceType" type="String" value="2D" />
    <prop name="deviceBus" type="String" value="RS232" />
    <prop name="baudRate" type="String" value="115200" />
    <prop name="parity" type="String" value="None" />
    <prop name="portName" type="String" value=" COM1" />
    <prop name="flowControl" type="String" value="None" />
    <prop name="stopBits" type="String" value="1" />
    <prop name="dataBits" type="String" value="8" />
</JposEntry>

<?xml version="1.0" encoding="UTF-8"?>
<!DOCTYPE JposEntries PUBLIC "-//JavaPOS//DTD//EN"
           "jpos/res/jcl.dtd">
<JposEntries>

</JposEntries>
```

Note: The default baud rate : 2D scanner =115200


How to use USB scanner with JavaPOS Driver

Configuring the Scanner via barcodes:

- Scan the barcodes in the sequence below to configure the scanner to usb-serial mode.

JavaPOS configuration bar codes:


Set




USB Virtual COM Port



JPOS Enable



End



Install the Java RXTXcomm API

In the \RXTXcomm folder, there are four files: rtxSerial.dll , rtxParallel.dll, and RXTXcomm.jar. Please do the following steps to install the library.

1. Copy rtxSerial.dll and rtxParallel.dll to C:\Windows\system32
2. Copy RXTXcomm.jar to your <JRE Install Folder>\lib directory.

Running the JavaPOS Test utility

Please run the test application to evaluate your installation.

How to Use JavaPOS Driver at your application

1. In the “\Driver” folder, copy “**ZbtJavaPos.jar**” and “**jpos.xml**” to your work folder.
2. Modify the jpos.xml .
3. Example of jpos.xml file content

```
<?xml version="1.0" encoding="UTF-8"?>
<!DOCTYPE JposEntries PUBLIC "-//JavaPOS//DTD//EN"
          "jpos/res/jcl.dtd">
<JposEntries>
<!--Saved by JavaPOS jpos.config/loader (JCL) version 2.2.0 on 2010/3/11 10:16-->

<JposEntry logicalName="Z3172P">
    <creation factoryClass="com.zbt.jpos.ZbtJposServiceInstanceFactory"
serviceClass="com.zbt.jpos.ScannerService"/>
    <vendor name="" url="" />
    <jpos category="Scanner" version="1.7" />
    <product description="Scanners" name="Scanner" url="" />

    <!--Other non JavaPOS required property (mostly vendor properties and bus specific properties i.e.
RS232 )-->
    <prop name="deviceType" type="String" value="2D" />
    <prop name="deviceBus" type="String" value="RS232" />
    <prop name="baudRate" type="String" value="115200" />
    <prop name="parity" type="String" value="None" />
    <prop name="portName" type="String" value=" COM56" />
    <prop name="flowControl" type="String" value="None" />
    <prop name="stopBits" type="String" value="1" />
    <prop name="dataBits" type="String" value="8" />
</JposEntry>

<?xml version="1.0" encoding="UTF-8"?>
<!DOCTYPE JposEntries PUBLIC "-//JavaPOS//DTD//EN"
          "jpos/res/jcl.dtd">
<JposEntries>
</JposEntries>
```