



































 000A0 Version (custom)	 000A1 Display inward character string (custom)	 000A2 Display series number (custom)
 000B0 Factory Default		 000600 PS2
 000601 RS-232	 000602 USB-HID	
 013300 Default Scan Mode	 013301 Single not triggered Not: CCD inapplicability	 013302 Key Delay No: CCD inapplicability
 013303 Key Delay not triggered Not: CCD inapplicability	 013304 Continuous Scan Mode	 013305 Auto flashing
 014201 Sound On Default	 014200 Sound Off	
 014300 High Volume Sound	 014301 Low Volume Sound	
 01400 Code ID Off default	 01401 Code ID On	 01402 Rear Code ID On
 01403 Code ID Off	 01404 Code ID On	 01405 Code ID Off

0005000 English Default	0005001 Canada-French	0005002 Netherlands-Dutch
 0005003 Spain-Spanish	 0005004 Argentina-Latin American	 0005005 Brazil-Portuguese
 0005006 Denmark-Danish	 0005007 UK-English	 0005008 Italy-Italian
 0005009 France-French	 0005010 Germany-German	 0005011 Norway-Northern Sami
 0005012 Sweden, Finland- Swedish, Finnish	 0005013 Slovakia-Slovak	 0005014 Portuguesa-Portuguese
 0005015 Czech Republic-Czech	 0005016 Belgium -Dutch	 0005017 Turkey-F
 0005018 Turkey-Q	 0005019 Poland-Polish	 0005020 Switzerland - German, French
 0005021 Croatia-Srb-Crt	 0005022 Hungary -Hungarian	 0005023 Japan-Japanese
 0005024 Russia-Russian		
 000701 Baudrate600bps	 000702 Baudrate1200bps	 000703 Baudrate2400bps
 000704 Baudrate4800bps	 000705 Baudrate9600bps Default	 000706 Baudrate19200bps

 000707 Baudrate38400bps	 000708 Baudrate57600bps	 000709 Baudrate115200bps
 001200 Serial Port no Check	 001201 Serial port :XON/OFF	 001202 Serial port:RTS/CTS
 001203 Serial port:ACK/NAK	 0013020 Serial port handshake timeout 2S	 0013050 Serial port handshake timeout 5S
 001500 Fastest transmit rate	 001502 Medium transmit rate Default	 001504 Lower transmit rate
 001506 Lowest transmit rate	 00161 Forward image identifyDefault	 00160 Reverse image identify
 00221 Enable code39	 00220 Disable code39	 0031m code39 IDAs m
 00231 Enable code39FullASCII Default	 00230 Disable code39 FullASCII	 00240 Disable code39 MOD43Check Default
 00241 Enable code39 MOD43Check	 00251 Enablecode39transmit check	 00250 Disable code39transmit check
 00280 Disable code39transmit * default	 00281 Enable code39transmit*	 00331 Enable code39Multiple verify
 00330 Disable code39Multiple verify default	 02080 Disable TWO replace 2 in Code 39	 02081 Enable TWO replace 2 in Code 39

 01950 Disable code32 Default	 01951 Enable code32 Note:will affect Code39	 0212M\t Code39 TABMode
 00321 code39Minimum length 1	 00322 code39 Minimum length 2 Default	 00323 code39 Minimum length 3
 00341 Enable UPC-A Default	 00340 Disable UPC-A	 0049e UPC-AIDAs e
 00391 Enable UPCChange to EAN13	 00390 Disable UPCChange to EAN13 Default	 00421 Transmit UPCACheck digit Default
 00420 NO-Transmit UPCACheck digit	 00400 UPCADisplay system digit	 00401 UPCAHide system digit
 00351 Enable UPC-E Default	 00350 Disable UPC-E	 0050f UPCEID As f
	 00381 Enable UPCE Change to UPCA	 00380 Disable UPCE Change to UPCA Default
 00361 Enable EAN13 Default	 00360 Disable EAN13	 0051d EAN13ID As d
	 00461 Transmit EAN13Check digit Default	 00460 No-Transmit EAN13Check digit

	 00481 Enable EAN13Change to ISBN	 00480 Disable EAN13Change to ISBNDefault
	 01501 Enable EAN13Change to ISSN	 01500 Disable EAN13Change to ISSN Default
	 00541 Enable EAN13Multiple verify	 00540 Disable EAN13Multiple verify Default
 00371 Enable EAN8 Default	 00370 Disable EAN8	 0052c EAN8IDAs c
	 00571 EAN8 Transmit check digit Default	 00570 EAN8 No-Transmit check digit
	 00561 EAN8 Hide system digit	 00560 EAN8 display system digit Default
 00552 Enable Fifth digit additional character	 00551 Enable Second digit additional character	 00553 Enable 2 <sup>nd</sup> & 5 <sup>th</sup> digit additional character
		 00550 Disable additional character Default

 00621 Enable code93 Default	 00620 Disable code93	 0066i code93ID As i
	 00681 Enable code93Multiple verify	 00680 Disable code93Multiple verify Default
	 01901 Enable Code 93MOD47 Default	 01900 Disable Code 93 MOD47
 00691 Enable code128 Default	 00690 Disable code128	 0081a code128ID As a
	 00840 Disable code128 Multiple verify  Default	 00841 Enable code128 Multiple verify
 00851 Enable codabar Default	 00850 Disable codabar	 0094v codabarID As v
 00874 Codabar Minimum length 4	 00861 Codebar start/stop character tansmission	 00860 Codabartart/stop character without tansmission Default
	 00951 Enable codabar Multiple verify	 00950 <u>Disable</u> codabar Multiple verify Default

 00961 Enable interleaved 2 of 5 Default	 00960 Disable interleaved 2 of 5	 0104n Interleaved 2 of 5ID As n
 00974 Interleaved 2 of 5Minimum length 4	 01050 Disable Interleaved 2 of 5 multiple verify Default	 01051 Enable Interleaved 2 of 5 multiple verify Default
 01061 Enable industrial 2 of 5 Default	 01060 Disable industrial 2 of 5	 0113o Industrial 2 of 5ID As o
 01073 Industrial 2 of 5 minimum length 3	 01141 Enable Industrial 2 of 5 multiple verify	 01140 Disable Industrial 2 of 5 multiple verify Default
 01151 Enable MSI	 01150 Disable MSIDefault	 0053s MSIID As s
 01184 MSI minimum length 4	 01250 Disable MSI Multiple verify	 01251 Enable MSI Multiple verify Default
 01161 Enable Plessey	 01160 Disable Plessey Default	 0117t PlesseyID As t
 01193 Plessey Minimum length 3	 01240 Disable PlesseyMultiple verify Default	 01241 Enable PlesseyMultiple verify
 01261 Enable code11 default	 01260 Disable code11	 0131u code11ID As u

 01284 Code11 Minimum length 4	 01320 Disable code11 Multiple verify Default	 01321 Enable code11 Multiple verify
 01271 Code11 Auto CK Check	 01272 Code11 C Check Default	 01273 Code11 CK Check
 01461 Enable Matrix 25 Default	 01460 Disable Matrix 25 Default	 00147q Matrix 25ID As q
	 01482 Matrix 25 Minimum length 2	 01483 Matrix 25 Minimum length 3
 01571 Enable postal 25	 01570 Disable postal 25 Default	 0158r Postal 25ID As r
	 01595 Postal 25 Minimum length 5	 01597 Postal 25 Minimum length 7
 01871 Enable aerial25	 01870 Disable aerial25 Default	 0188p Aerial 25ID Asp
	 01897 Aerial 25 Minimum length 7	



 01671 (only SUC2, CCD) Enable GS1 Omnidirectional	 01670 (only SUC2, CCD) Disable GS1 Omnidirectional Default	 0168j (only SUC2, CCD) GS1 OmniID As j
 01771 (only SUC2, CCD) Enable GS1 Limited	 01770 (only SUC2, CCD) Disable GS1 Limited Default	 0178k (only SUC2, CCD) GS1 LimitedID As k
 01640 FUNC cast light upon cancel Default	 0160049 FUNC1 Replace with 1	 0161050 FUNC2 replace with 2
	 0162051 FUNC3 replace with 3	 0163054 FUNC4 replace with 4
 0182013 Disable Enter replace Default	 0182055 Enter replace with 5	
 0201x Display Code Front Character Default	 0200 [SPACE] Hide Code Front Blank	
 0203 Display Code Rear character Default	 0202 [SP] Hide Code Rear Character	
 0205- Display Characters inside Code Default	 0204- Hide - inside code	
 020600 Disable A replace 0 in code Default	 02060A Enable A replace 0 in code	

































 02070 Disable One replace 1 in code Default	 02071 Enable One replace 1 in code	
 02090 Remain character before 12345 Default	 02091 Remove character before 12345	
 02301 Enable USB fast data upload Default	 02300 Disable USB fast data upload	
 02311 Enable IR Auto-sensing Default	 02310 Disable IR Auto-sensing	
 023300 Display rear characters Default	 023305 Hide rear 5 characters	 023301 Hide rear 1 character
 023400 Display front characters	 023405 Hide front 5 characters	
 023900 Display middle characters Default	 023905 Hide 5 middle characters	 024004 Forward start from 4 <sup>th</sup> character
 023530 Trigger timeout 3s Laser default	 023500 None trigger timeout CCD default	 023550 Trigger timeout 5s Laser
 02361 All EAN change to ISBN	 02360 Disable EAN change to ISBN Default	








































 02371 All EAN change to ISSN	 02370 Disable EAN change to ISSN Default	
 02501 Enable upload setting barcodes	 02500 Disable upload setting barcodes Default	
Wireless Scanner special Settings		
 03000 Compulsory pairing (Clear previous pair)	 03001 Pair (None paired device)	 03060 Display stored data quantity
 03061 Quantity of available data	 03062 Display receiver address	 03063 Display transmitter address
 03011 Dongle Address		
Prefix/Suffix Setting		
 0212@r CR	 0213@r\n CR+LF	 0211@[ETX] All barcodes(rear) add ETX
 02160081 All barcodes(front) addF2	 02110081 All barcodes(rear) addF2	 0210@ Cancel all barcodes(rear) format character








































 0217@[STX] Add STX before barcodes	 0215@ Cancel all boots before barcodes	 02240 Add prefix
 02241 Add suffix	 02242 Exit add pre/suffix Mode	 02220 Clear all prefix
 02200 Clear all suffix		

## Character

 1001 SOH Note: Used to add Prefix/Suffix	 1002 STX Note: Used to add Prefix/Suffix	 1003 ETX Note: Used to add Prefix/Suffix
 1004 EOT Note: Used to add Prefix/Suffix	 1005 ENQ Note: Used to add Prefix/Suffix	 1006 ACK Note: Used to add Prefix/Suffix
 1007 BEL	 1008 Backspace	 1009 TAB
 1010 Line	 1011 VT	 1012 FF
 1013 Enter	 1014 SO	 1015 SI
 1016 DLE	 1017 DC1	 1018 DC2
 1019 DC3	 1020 DC4	 1021 NAK
 1022 SYN	 1023 ETB	 1024 CAN

 1025 EM	 1026 SUB	 1027 ESC
 1028 FS	 1029 GS	 1030 RS
 1031 US	 1032 SPACE	 1033 !
 1034 "	 1035 #	 1036 \$
 1037 %	 1038 &	 1039 '
 1040 (	 1041 )	 1042 *
 1043 +	 1044 ,	 1045 -
 1046 .	 1047 /	 1048 0 Note:Used to set Address/prefix/suffix
 1049 1 Note:Used to set Address/prefix/suffix	 1050 2 Note:Used to set Address/prefix/suffix	 1051 3 Note:Used to set Address/prefix/suffix
 1052 4 Note:Used to set Address/prefix/suffix	 1053 5 Note:Used to set Address/prefix/suffix	 1054 6 Note:Used to set Address/prefix/suffix
 1055 7 Note:Used to set Address/prefix/suffix	 1056 8 Note:Used to set Address/prefix/suffix	 1057 9 Note:Used to set Address/prefix/suffix

 1058 :	 1059 ;	 1060 <
 1061 =	 1062 >	 1063 ?
 1064 @	 1065 A	 1066 B
 1067 C	 1068 D	 1069 E
 1070 F	 1071 G	 1072 H
 1073 I	 1074 J	 1075 K
 1076 L	 1077 M	 1078 N
 1079 O	 1080 P	 1081 Q
 1082 R	 1083 S	 1084 T
 1085 U	 1086 V	 1087 W
 1088 X	 1089 Y	 1090 Z
 1091 [	 1092 \	 1093 ]
 1094 ^	 1095 _	 1096 ,

 1097 a	 1098 b	 1099 c
 1100 d	 1101 e	 1102 f
 1103 g	 1104 h	 1105 i
 1106 j	 1107 k	 1108 l
 1109 m	 1110 n	 1111 o
 1112 p	 1113 q	 1114 r
 1115 s	 1116 t	 1117 u
 1118 v	 1119 w	 1120 x
 1121 y	 1122 z	 1123 {
 1124 	 1125 }	 1126 ~
 1127 Delete	 1128 F1	 1129 F2
 1130 F3	 1131 F4	 1132 F5
 1133 F6	 1134 F7	 1135 F8

 1136 F9	 1137 F10	 1138 F11
 1139 F12	 1140 INSERT	 1141 HOME
 1142 Page up	 1143 Delete	 1144 END
 1145 Page down	 1146 Right arrow	 1147 Left arrow
 1148 Down arrow	 1149 Up arrow	
 02510 Disable Change	 02511 All Uppercase	 02512 All lowercase
 02513 Uppercase interchange with Lowcase	 02520 Disable long press manage Note:Wireless scanner not support	
 02530 Disable scan vibrate	 02531 Enable scan vibrate	 02521 Enable long press manage Note:Wireless scanner not support
<h2 style="color: red;">Wireless Scanner Special Settings</h2>		
 03000 Compulsory pairing	 03010 Set scanner address	 000605 Wireless Mode
 000607 Auto data save mode	 000606 Inventory mode	 03020 Dongle Add



	 03070 Data Clear	 03050 Resume data upload
 03120 Disable beeper when data succeed upload	 03121 Enable beeper when data succeed upload	 03111 Device turn off
 0303000 Upload all data and clear	 0303001 Upload 1 data and clear	 0304000 Upload all data and reserve
 0304001 Upload 1 data and reserve	 03061 Display quantity of rest data	 0310060 Auto turn off in 60s